

Link-11 2.3.0.0:SUM1.0

**Defense Information Infrastructure (DII)  
Common Operating Environment (COE)**

# **Software User's Manual**

## **Link-11/TADIL A**

**Version 2.3.0.0**

**14 April 1997**

Prepared for:

Defense Information Systems Agency (DISA)

Prepared by:

Inter-National Research Institute, Inc. (INRI)  
10101 Old Grove Road  
San Diego, CA 92131



# *Table of Contents*

---

Link-11 Introduction .....	1
Link-11 Implementation Options .....	1
Setting up a Link-11 Communications Channel .....	3
Link-11 Channel Edit Window .....	4
Communications Pop-Up Options for Link-11 .....	6
Dialog Manager .....	12
Configure Message Attributes .....	14
New Link Track .....	17
Surface .....	18
Subsurface .....	26
ASW Bearing.....	29
Electronic Support Message (ESM) .....	33
Area of Probability (AOP).....	37
Sonobuoy .....	40
Special Point.....	43
Pointer .....	46
NOTACK .....	48
Acoustic Bearing .....	50
Air .....	52
ASW Tactical Point .....	55
NEW TRACK Pop-up Menus.....	57
Edit Link Track .....	59
View and Edit Windows .....	59
VIEW WINDOW Pop-up Menus.....	62
EDIT WINDOW Pop-up Menus.....	63
Electronic Control Message (ECM) INTERCEPT REPORT.....	64
Search Link Tracks.....	67
Pair/Associate Link Tracks .....	68
Information Difference.....	70
Set Engagement Status .....	72

Xmit on Link .....	74
Stop Xmit.....	75
Gridlock .....	76
GEO Filter.....	78
Add a Filter.....	80
Edit a Filter.....	86
Update Request .....	87
Receive Quality .....	88
Send Aircraft Control Order .....	91
Command Messages .....	92
Received Command Messages .....	93
Send Command Message .....	94
View Command Message.....	95
Monitor Database Size.....	96
Read Plain Text .....	97
View Plain Text Messages .....	98
Create New Plain Text Message.....	100
Create Plain Text Message.....	103
View Transmitted Plain Text Messages .....	104
Create New Plain Text Message.....	106
ASW Summary.....	109
XMIT DLRP .....	110
Link Supervisor .....	111
Track Block Assignment.....	112
Weapon Status .....	114
Link Status .....	116
Programmed Operational Functional Appraisal (POFA).....	118
Edit POFA Window.....	119
POFA Single- or Multi- Station Summary Window.....	121

Configure.....	123
Bit Display.....	124
Interrupt Codes.....	126
Multi-Station Matrix .....	127
Appendix A: TADIL-B.....	A-1
Link-11 Channel Edit Window.....	A-2
TADIL-B Supervisor .....	A-3
Receive Quality .....	A-4
Link Status .....	A-5
GEO Filters .....	A-7
Appendix B: MX512P Channel.....	B-1
Data Terminal Set Control Head .....	B-4
Appendix C: Acronyms .....	C-1

## Notes

# *Link-11 Introduction*

---

The Link-11 interface (LINK11ACT), also known as TADIL A, provides the capability to transmit as well as receive Link-11 messages. Although there are some differences between Link-11 and TADIL A, this manual will refer to the system as “Link-11” throughout the document.

Install the Link-11 component using the segment Installer option in the System Administration SOFTWARE pull-down menu. Install both the Link-11 and the Link-11 Admin segments to enable the Active Link capability.

The TADIL A pull-down menu in the System: Default Mode window menubar contains options for Link track management.


## ***Important:***

- All Link-11 menu options and window fields are described in this document.
- Each implementation, such as US Coast Guard or Submarine, will display only an appropriate subset of the options and window fields described in this document.
- Some options and window fields may be unavailable for the selected implementation.

## **Link-11 Implementation Options**

Select the appropriate implementation of Link-11 before starting the Link-11 interface.

**To access this window:** TADIL A pull-down menu (System Administration) : SELECT IMPLEMENTATION option.



> To set implementation:

1. Ensure that Ownstation is set to an appropriate category for the implementation. For example, Ownstation must be SUB for SUBMARINE implementation.
2. Highlight the appropriate implementation.
3. Click OK to accept the selection or CANCEL to discard it.

If it is necessary to change implementation, stop the Link channel and delete all link tracks before opening the IMPLEMENTATION window.



## Setting up a Link-11 Communications Channel

Use the COMMUNICATIONS option in the COMMS pull-down menu to specify settings to add, configure, start, and stop the Link-11 communications channel. For a thorough discussion of this option, refer to the Communications section of the Comms chapter in the *Software User's Manual, Unified Build (TMS/UCP)*.

**To access this window:** COMMS pull-down menu : COMMUNICATIONS option.

NAME	XRF	INT	INTERFACE	MACHINE	DEVICE	STARTUP
LINK11	2WL	INT	LINK11ACT	MACH1	NTDSO	MANUAL OFF
GFCPLAN	GFP	INT	GFCPLAN	MACH1	LAN	MANUAL ON
GFCP-TERM		INT	VT100TERM	MACH1	TTYA	MANUAL OFF
FCSA	FCA	INT	FCS	MACH1	NTDS1	MANUAL OFF
FCSB	FCB	INT	FCS	MACH2	NTDS1	MANUAL OFF
SERIAL	SRL	INT	SERIAL	MACH1	TTYA	MANUAL OFF
OTCIXS	OTC	INT	OTCIXS		TTYA	MANUAL OFF

ADD EDIT DELETE EXIT

The COMMUNICATIONS window displays a list of communications channels available in the system.

- A Link-11 channel and interface must be added to this list and turned on after the Link-11 segment is loaded.
- The COMMUNICATIONS window may contain a maximum of 32 channels. An existing channel may need to be deleted before adding the Link-11 channel.
- Detailed instructions for adding a new channel can be found in the Comms chapter of the *Software User's Manual, Unified Build (TMS/UCP)*.

To start a Link-11 channel, highlight the channel in the COMMUNICATIONS window and choose START from the pop-up menu. Some or all of these three windows appear in succession (depending on the selected implementation) to prompt the Link Supervisor to set up Link-11 communications parameters:

- TRACK BLOCK ASSIGNMENT (described in *Track Block Assignment*).

- WEAPON STATUS (described in *Weapon Status*).
- LINK CONFIGURATION (described in *Link Status*).

## Link-11 Channel Edit Window

To view and edit Link-11 channel settings, highlight the Link-11 channel in the COMMUNICATIONS window and click EDIT to open the EDIT LINK11 window. (Note: Window fields for TADIL-B are described in Appendix A.)

The screenshot shows the 'EDIT LINK11 ACTIVE' window. It contains several sections for configuring the Link-11 channel:

- CHANNEL**
  - NAME ..... LINK11
  - INTERFACE ... LINK11ACT
  - DEVICE ..... NTDS0 (with a dropdown arrow)
  - MACHINE ..... MACH1 (with a dropdown arrow)
- SUPERVISOR**
  - MACHINE .... MACH 1 (with a dropdown arrow)
  - DISPLAY ..... CONSOLE M (with a dropdown arrow)
- SOURCE**
  - ☒ LINK A
  - ☐ LINK B
  - ☐ LINK C
  - ☐ LINK D
- NTDS TYPE**
  - ☒ TYPE A (SLOW)
  - ☐ TYPE B (FAST)
  - ☐ TYPE C (ANEW)
- POSITIONING**
  - ☒ COSINE CORRECTION
  - ☐ STEREOGRAPHIC
- DEFAULT TRACK TYPE**
  - ☒ REAL WORLD
  - ☐ LIVE TRAINING
  - ☐ SIMULATED

At the bottom of the window are two buttons: '- OK -' and 'CANCEL'.

> To edit a Link11ACT channel:

1. In the CHANNEL box:

- Click the DEVICE select button and choose a device name

from the list.

- Click the **MACHINE** select button and choose a machine from the list.
2. In the **SUPERVISOR** box:
    - Click the **MACHINE** select button and choose a machine to be the Link Supervisor.
    - Click the **DISPLAY** select button and choose a monitor where alerts will be displayed.
  3. In the **SOURCE** box:
    - Choose one diamond knob as the Link Source.
  4. In the **POSITIONING** box:
    - Choose one diamond knob as the method of calculating track position.
    - The transmitting unit and the receiving unit must select the same method to ensure tracks are displayed in identical positions.
  5. In the **DEFAULT TRACK TYPE** box:
    - Choose one diamond knob to define the default track type.
  6. Click **OK** to accept the new settings or **CANCEL** to discard.

#### EDIT LINK11 Window Fields:

##### *CHANNEL Box*

###### **NAME**

Name of the channel. This field cannot be edited.

###### **INTERFACE**

Communications interface for the channel. This field cannot be edited.

###### **DEVICE**

Name of NTDS device.

###### **MACHINE**

Name of the machine used to transmit or receive message on this channel.

##### *SUPERVISOR Box*

Only one machine can be designated the Link Supervisor. This is the only

machine that can be used to:

- define track block assignments
- define weapon status
- define Link configuration
- receive alerts

**MACHINE**

Name of machine designated as Link Supervisor.

**DISPLAY**

Monitor where alerts will be displayed.

*SOURCE Box*

Designates Link source: LINK A, LINK B, LINK C, or LINK D.

*NTDS TYPE Box*

Designates type of NTDS: TYPE A (FAST), TYPE B (SLOW), or TYPE C (ANEW).

*POSITIONING Box*

**COSINE CORRECTION**

Method of calculating track positions.

**STEREOGRAPHIC**

Alternate method of calculating track positions.

*DEFAULT TRACK TYPE Box*

**REAL WORLD**

Exists in the real world.

**LIVE TRAINING**

Exists in the real world, but used for exercise purposes and may be assigned a different identity, such as a friendly track being identified as hostile.

**SIMULATED**


Does not exist in the real world; being created for exercise and scenario purposes.

## Communications Pop-Up Options for Link-11

All pop-up options function as described in the *Software User's Manual, Unified Build (TMS/UCP)*.

## LINK-11 STATUS Window

Highlight a Link-11 channel in the COMMUNICATIONS window and select WINDOW from the pop-up menu to open the LINK11 STATUS window.



### About the LINK-11 STATUS Window:

The LINK-11 STATUS window displays a scrolling list of messages transmitted or received on the channel.

- The list holds up to 100 messages.
  - The list is automatically updated.
  - When the list contains 100 messages, the oldest messages are overwritten with new messages.
  - A blank line appears at the end of the list.
- Diamond knobs determine the type of messages displayed.
- Message contents can be viewed by clicking on a message in the list (see *View a Message*).

### LINK-11 STATUS Window Actions:

- > **ARCHIVE**—save the list of messages to a selected file. (Described in *Archive Files*.)
- > **CLEAR**—removes all messages from the scroll list.

- > EXIT—closes the window.
- > PAUSE/RESUME—pauses the scrolling list, or resumes scrolling.

#### LINK-11 STATUS Window Fields:

**TX & RX**

Transmitted and received messages.

**TX ONLY**

Transmitted messages only.

**RX ONLY**

Received messages only.

**EF & TX & RX**


External functions, received and transmitted messages. Extended functions include Prepare to Transmit (PTT) and Prepare to Receive (PTR) messages.

**OFF**

Link activity is not monitored.

### *View a Message*

To view the message contents, click on a message in the scrolling list of the LINK-11 STATUS window to open the DECODED MESSAGE window.




## DECODED MESSAGE Window Actions

- > RAW—view raw data for the message.
- > SEARCH—not yet implemented.
- > ARCHIVE—save the message to a selected file. (Described in *Archive Messages*.)
- > PREVIOUS—view the previous message in the LINK-11 STATUS scrolling list.
- > NEXT—view the next message in the LINK-11 STATUS scrolling list.
- > OK—close the window.

## View Raw Message Data

To view raw data for the selected message, click RAW in the DECODED MESSAGE window to open the RAW MESSAGE window.




## RAW MESSAGE Window Actions

- > SEARCH—not yet implemented.
- > ARCHIVE—save the raw message to a selected file. (Described in *Archive Messages*.)

- > PREVIOUS—view the previous message in the LINK-11 STATUS scrolling list.
- > NEXT—view the next message in the LINK-11 STATUS scrolling list.
- > OK—close the window.

## Archive Messages

Click ARCHIVE to open the DESTINATION FILE window.



### About the DESTINATION FILE Window:

- Messages can be archived to a user-defined file in the default directory or to a user-defined directory and file.
    - The default directory is /tmp/vids.
    - This directory is *temporary*—contents are deleted each time the system is started.
  - The window lists the directories, or files within a highlighted directory, that meet the filter parameters.
- > To archive messages:
1. Use the FILTER field to search for directories or files that match filter parameters.



- 
- To search for directories: enter filter parameters and click FILTER.
  - To search for files within a directory: highlight a directory in the scroll list, enter filter parameters, and click FILTER.
2. In the SELECTION field, enter the path name of the file for the archived messages.
    - Enter a new file name, or select an existing file from the FILES list.
    - If messages are saved in an existing file, the new archive information will overwrite the contents of the file.
  3. Click OK to save the file, or CANCEL to discard the process.

## Dialog Manager

Use the DIALOG MANAGER to:

- configure an alert filter for messages.
- view scrolling lists of messages in ACTION and NO ACTION categories.

The DIALOG MANAGER window opens when the Link-11 channel is started.

ACTION					
KIND	STATE	DTG	ACTION/MESSAGE	RESPONSE DTG	RESPONSE
MANAGEMENT	PENDING	161248Z AUG 96	Link11 Startup Override Delay	...	No Response REQ

NO ACTION					
KIND	STATE	DTG	ACTION/MESSAGE	RESPONSE DTG	RESPONSE
MANAGEMENT	OBE	161248Z AUG 96	Link11 Startup	161248Z AUG 96	Acknowledged

VIEW DELETE CONFIG CLOSE

### About the DIALOG MANAGER Window:

- Messages in the ACTION list:
  - create an entry in the list and open an alert window on the screen (if set to display) prompting the user for a response.
  - are displayed in red until there is a response.
  - are moved to the NO ACTION list and displayed in yellow after the user responds.
- Messages in the NO ACTION list
  - create an entry in the list and open an alert window on the screen if set to display.
  - The only response required is to click OK.
  - are displayed in yellow.

- Click the small box on the horizontal line between the two sections and drag up or down to adjust the size of each section.

## DIALOG MANAGER Window Actions

- > CLOSE—the window.
  - The window becomes an icon at the bottom of the screen (shown below).
  - The colors of the icon invert when alerts are pending, or waiting for a response.
  - Double-click the icon to open the window.



- > CONFIG—the alert filter (described in *Configure Message Attributes*).
- > DELETE—a message.
  1. Highlight one or more messages in either list.
  2. Click DELETE.
- > SELECT ALL (pop-up option)—select all messages in both lists.
- > SELECT ALL ACTION (pop-up option)—select all messages in the ACTION list.
- > SELECT ALL NO ACTION (pop-up option)—select all messages in the NO ACTION list.
- > UNSELECT ALL (pop-up option)—deselect all messages in both lists.
- > UNSELECT ALL ACTION (pop-up option)—deselect all messages in the ACTION list.
- > UNSELECT ALL NO ACTION (pop-up option)—deselect all messages in the NO ACTION list.

- > **VIEW**—open an alert window to respond to a message.

### **DIALOG MANAGER Window Fields**

#### **KIND**

Kind of message.

**MANAGEMENT**—such as Link Startup messages

**ALERT**—such as Reporting Responsibility changes

**INTERNAL**—such as Database full

#### **STATE**

**PENDING**—message awaiting response

**OVERCOME BY EVENTS (OBE )**—message acknowledged or expired. (Some alerts will disappear from the screen after a set length of time without operator action, such as Link Startup and Link11 Startup Override Delay.)

#### **DTG**

Date and time of message.

#### **ACTION/MESSAGE**

Name of message.

#### **RESPONSE DTG**

Date and time of response.

#### **RESPONSE**

Response to message.

## **Configure Message Attributes**

Use this DIALOG MANAGER window to configure the alert filter. Click **CONFIG** in the DIALOG MANAGER window.

**Link11-A: Dialog Manager**

Configure Message Attributes

Message Type	Window	Screen Position	Maximum Number
Link Startup	<input type="checkbox"/> Displayed	<input checked="" type="checkbox"/> Stack Left <input type="checkbox"/> Stack Right <input type="checkbox"/> Cascade Center	<input type="text" value="1"/>
Link11 Startup Override Delay	<input type="checkbox"/> Displayed	<input checked="" type="checkbox"/> Stack Left <input type="checkbox"/> Stack Right <input type="checkbox"/> Cascade Center	<input type="text" value="1"/>
Air Control Attempt	<input type="checkbox"/> Displayed	<input checked="" type="checkbox"/> Stack Left <input type="checkbox"/> Stack Right <input type="checkbox"/> Cascade Center	<input type="text" value="25"/>
Aircraft Control Orders	<input type="checkbox"/> Displayed	<input checked="" type="checkbox"/> Stack Left <input type="checkbox"/> Stack Right <input type="checkbox"/> Cascade Center	<input type="text" value="25"/>
ASW Summary Notify	<input type="checkbox"/> Displayed	<input checked="" type="checkbox"/> Stack Left <input type="checkbox"/> Stack Right <input type="checkbox"/> Cascade Center	<input type="text" value="25"/>

- > To configure the alert filter:
  1. Click the diamond knobs and checkboxes to set message attributes for each message type.
  2. Set maximum number for each message type.
  3. Click APPLY to save the changes, or click CANCEL to discard.

#### DIALOG MANAGER Window Actions

- > **DEFAULT**—sets all DISPLAYED fields in the WINDOW column to ON and all SCREEN POSITIONS to CASCADE CENTER.
- > **ALL DISPLAYED** (pop-up menu)—toggles all DISPLAYED checkboxes ON.
- > **ALL NOT DISPLAYED** (pop-up menu)—toggles all DISPLAYED checkboxes OFF.

- > ALL STACK LEFT (pop-up menu)—toggles all SCREEN POSITION to STACK LEFT.
- > ALL STACK RIGHT (pop-up menu)—toggles all SCREEN POSITION to STACK RIGHT.
- > ALL CASCADE CENTER (pop-up menu)—toggles all SCREEN POSITION to CASCADE CENTER.
- > APPLY (pop-up menu)—saves changes and closes window.
- > CLOSE (pop-up menu)—closes the window without saving changes.

#### DIALOG MANAGER Window Fields

**MESSAGE TYPE**

Type of alert.

**WINDOW**

Designate if an alert is displayed.

**SCREEN POSITION**

Designate where alerts display on screen.


**MAXIMUM NUMBER**

Maximum number of each message type allowed in the list. When the maximum number is reached, the oldest messages are deleted.

## New Link Track

To create a new Link track, at least one Link-11 ACT channel must be activated.

**To access this window:** TADIL A pull-down menu : NEW LINK TRACK option.



- > To create a new track:
1. Click on the TRACK TYPE select button and choose a track type from the list.
  2. Click OK to accept the track type or CANCEL to discard.
  3. A unique track report window opens for each track type. (Described in the following sections.)

### Track Type Field:

Note: Only the track types appropriate for the selected implementation are available in the TRACK TYPE list.

#### **SURFACE**

Track for a surface vessel.

#### **SUBSURFACE**

Track for a subsurface vessel.

#### **ASW BEARING**

A line of bearing track for Anti-Submarine Warfare (ASW) systems.

#### **ESM**

Electronic Support Message (ESM) track.

**AREA OF PROBABILITY**

Ellipse indicating the probable area a track is located.

**SONOBUOY**

Track for a sonobuoy.

**SPECIAL POINT**

Track with special significance, used mostly for hazards, emergencies, or search and rescue.

**POINTER**

Track of special importance.

**NOTACK**

Friendly area of “no attack” for a specified length of time.

**ACOUSTIC BEARING**

Line of bearing track for ASW systems. Reports are generated from passive sonar systems, based on sounds emitted by the track.

**AIR**

Track for aircraft.

**ASW TACTICAL POINT**

Track for specific ASW point types, including:

SINKER

BRIEF CONTACT

ASW SEARCH CENTER

SONOBUOY PATTERN CENTER

ASW STATION

CHARTED WRECK

ASW SUBSURFACE STATION

SONOBUOY REFERENCE CENTER

BOTTOMED NON-SUBMARINE

FIX

ESTIMATED POSITION (EP)

## Surface

Select SURFACE track type from the NEW TRACK window and click OK to open the NEW SURFACE TRACK REPORT window.



LINK11-A: REAL-WORLD - NEW SURFACE TRACK REPORT		
SUR TRACK		
<b>TRACK NUMBERS</b> LTN ..... FTN ..... CTSX ..... STN ..... JTN ..... PARENT ..... UID .....	<b>RELATED INFORMATION</b> PU/RU 030 has Reporting Responsibility No associated tracks  <div>TRACK ASSOC</div> <div>DELETE</div>	<b>STATUS</b> <input type="checkbox"/> EMERGENCY STATUS <input type="checkbox"/> FORCE TELL STATUS <input type="checkbox"/> SPI <input type="checkbox"/> TRANSMIT ENABLED <input type="checkbox"/> RECEIVED <input type="checkbox"/> TEST DATA
<b>ATTRIBUTES</b> STN ..... NICK NAME. .... ID ..... <div>UNKNOWN</div> PRI AMP ..... <div>PENDING/UNEVAL</div> ID AMP ..... <div>NS</div> MODE1 IFF ..... MODE2 IFF ..... MODE3 IFF ..... MODE4 IFF ..... DI ..... PU/RU ..... 030 TQ ..... <div>NON-REAL-TRACK</div> RAID SIZE ..... <div>NS</div> OBSERVE TIME. . . 00:57		<b>LAST REPORT</b> TIMELATE .... 000:09 RPT DTG .... 161248Z DEC 95 LAT/LONG .... 0505S 00318W GRID POS (NM) ..... CSE (T) ..... 000.0 SPD (KT) ..... 0000.0 ALTITUDE ..... AOU TYPE .... ELLIPSE AOU BRG (T) ... 000.0 SMJR (NM) .... 00009 SMNR (NM) .... 00009 SENSOR ..... SOURCE ..... NTDS XREF .....
<div>SAVE</div> <div>XMIT</div> <div>CANCEL</div>		

### How to Use the NEW SURFACE TRACK REPORT Window:

- Enter data.
  - Type data, such as NICK NAME.
  - Click the select button and choose a value, such as ID.
  - Set checkboxes.
- Save the information. (Or click CANCEL to discard it.)
  - SAVE saves the track, but does not transmit data.
  - XMIT transmits and saves the track.
- Invalid data entered into any field appears in red when SAVE or XMIT is clicked.

- Correct the data.
  - Click SAVE or XMIT again.
4. An alert displays if no numbers in the assigned Track Block are available.
- Contact the Link Coordinator to adjust the Link Track Block Assignment.

## NEW SURFACE TRACK REPORT Window Fields

### *TRACK NUMBERS Box*

The system assigns track numbers when a new track is saved. These fields are view-only.

#### **LTN**

Local track number, used internally by the system for track identification.

#### **FTN**

FOTC track number.

#### **CTSX**

Unique local Link track number, assigned when a track enters the Link.

#### **STN**

System track number. This is also known as the Naval Tactical Display System (NTDS) track number.

#### **JTN**

TADIL-J track number.

#### **PARENT**

Local track number of a Platform track (if the Link track is associated with a Platform track).

**UID (ashore sites only)**

Unique identifier for the track: three letters (site reporting the track) followed by a series of numbers (to uniquely identify the track).

*RELATED INFORMATION Box*

This box lists the following information:

- PU with reporting responsibility.
- Track associations
- AOP relationships
- Controlling relationships
- Identification for this track assigned by other Link channels.

**TRACK ASSOC**—opens the TRACK ASSOCIATION window (described in *Track Association Window*.)

**DELETE**—breaks a track association set by your system.

1. Highlight one associated track in the list.
2. Click DELETE to break the association.

*STATUS Box***EMERGENCY STATUS**

ON—overrides display filters; the track always displays.

OFF—obeys display filters.

**FORCE TELL STATUS**

ON—overrides display filters; the track always displays.

OFF—obeys display filters.

**SPI**

Special Processing Indicator.

ON—track derived from intelligence sources.

**TRANSMIT ENABLED**

Track is selected for transmission.

**RECEIVED**

Track is received from Link.

**TEST DATA**

Inactive.

*ATTRIBUTES Box***STN**

Manually entered System Track Number—overrides system-assigned number.

**NICK NAME**

Local name for the track. This name is not transmitted to other locations.

**ID**

Link-11 threat ID.

**PRI AMP**

Primary amplifier.

**ID AMP**

Further amplification of the identity of the track. Possible entries for this field are determined by the track type.

**MODE 1 IFF**

Identification Friend or Foe—code which gives a general description of the mission. Mode 1 IFF is for military use.

**MODE 2 IFF**

Code which provides an exact ID for the platform or track.

This number is used in track correlation and is also used with the PIF DON'T CARE and PIF NICKNAMES options from the TRACK TABLES option, found under the TRACKS menu.

**MODE 3 IFF**

Code describing the type of mission and the general direction of travel. Mode 3 IFF can be commercial, military, or can come from other sources. It can be either friendly or non-friendly.

**MODE 4 IFF**

Interrogation status.

**DI**

Discrete Identifier, which is a special four-digit code.

**PU/RU**

Participating or Reporting Unit. This identifies the reporting source. (This field is view-only.)

**TQ**

Track quality number as reported in the LINK. Values include NON-REAL-TRACK or a number between 1 and 7. The higher the number, the more accurate the report.

**RAID SIZE**

Number of objects in track.

**OBSERVE TIME**

Time track was observed. Field defaults to the current time when this window opens, and may be changed to the actual time the track was observed.

***LAST REPORT Box***

The LAST REPORT box displays information about the last reported position for the track. The LAT/LONG, CSE, and SPD fields can be edited. All other fields are view-only.

**TIMELATE**

Amount of time elapsed since report was received.

**RPT DTG**

Date-time group for the report.

**LAT/LONG**

Latitude and longitude of the reported position.

**GRID POS (NM)**

Grid x and y coordinates track is offset from DLRP.

**CSE (T)**

Course for track in degrees true.

**SPD (KT)**

Speed of track in knots.

**ALTITUDE**

Altitude for the track.

**AOU TYPE**

Area of uncertainty. Default type is an ELLIPSE with semi-major and semi-minor axes of 9 NM each.

**AOU BRG (T)**

AOU bearing for the track in degrees true.

**SMJR (NM)**

Semi-major axis length of the ellipse.

**SMNR (NM)**

Semi-minor axis length of the ellipse.

**SENSOR**

Sensor type used to pick up the track at its last reported position.

**SOURCE**

Source code, NTDS, for the track.


**XREF**

Source cross-reference code for the Command originating the track report.

### *Track Association Window*

Use this option to update track associations set by your system or view associated track numbers assigned by other systems on the Link.

Click TRACK ASSOC to open the TRACK ASSOCIATION WINDOW. Most implementations display the following window:



Track Association Window

Track C2000

19-Bit Track Number .....

REQUEST 19-BIT TN UPDATE SAVE CANCEL

#### How to use the TRACK ASSOCIATION WINDOW:

1. Associate a 19-bit track number with the track one of two ways:
  - Enter a number in the field.
  - Click REQUEST 19-BIT TN UPDATE to request an update to the 19-bit number from other PUs.
2. Click SAVE to save the changes, or CANCEL to discard.

Some implementations receive or transmit more detailed information and display additional fields, similar to the following window.

**Track Association Window**

Track C2000

Link-4A Address . . . . .

Voice Call Sign . . . . .

Link-1 NATO Track Number . . . . .

19-Bit Track Number . . . . .

Mission Number . . . . .

ATDL-1 Track Number . . . . .

Voice Control Frequency (MHz) . . . . .

Voice Control Channel Number . . . **None** Channel . . . .

Link-4A Control Frequency (MHz) . . . . .

Link-4A Control Channel Number. . . **None** Channel . . . .

**REQUEST 19-BIT TN UPDATE** **REQUEST NATO TN UPDATE** **SAVE** **CANCEL**

### How to use the TRACK ASSOCIATION WINDOW:

If the selected implementation transmits the information, the field can be edited.  
If transmission is not allowed, the fields are view-only.

1. Associate a 19-bit or NATO track number with the Link track one of two ways:
  - Enter a number in the field.
  - Click REQUEST 19-BIT TN UPDATE or REQUEST NATO TN UPDATE to request an update to the 19-bit OR NATO number from other PUs.
2. Select Voice Control Channel Number and Link-4A Channel Number.
  - Click select button and choose a group.
  - Enter channel number in the CHANNEL field.
3. Click SAVE to save the changes, or CANCEL to discard.

### TRACK ASSOCIATION WINDOW Fields:

#### **LINK-4A ADDRESS**

Address of aircraft.

#### **VOICE CALL SIGN**

Radio call sign for voice frequency.

**LINK-1 NATO TRACK NUMBER**

NATO track number.

**19-BIT TRACK NUMBER**

19-bit track number assigned to the track.

**MISSION NUMBER**

Mission number assigned to the track.

**ATDL-1 TRACK NUMBER**

ATDL track number assigned to the track.

**VOICE CONTROL FREQUENCY (MHz)**

UHF frequency for voice communications.

**VOICE CONTROL CHANNEL NUMBER**

Channel for voice communications.

**LINK-4A CONTROL FREQUENCY (MHz)**

UHF frequency for voice communications.

**LINK-4A CHANNEL NUMBER**

Channel for voice communications.

## Subsurface

Select SUBSURFACE track type and click OK to open the NEW SUBSURFACE TRACK REPORT window.



LINK11-A: REAL-WORLD - NEW SUBSURFACE TRACK REPORT		
SUB TRACK		
<b>TRACK NUMBERS</b> LTN ..... FTN ..... CTSX ..... STN ..... JTN ..... PARENT ..... UID .....	<b>RELATED INFORMATION</b> PU/RU 030 has Reporting Responsibility No associated tracks  <div>TRACK ASSOC</div> <div>DELETE</div>	<b>STATUS</b> <input type="checkbox"/> EMERGENCY STATUS <input type="checkbox"/> FORCE TELL STATUS <input type="checkbox"/> SPI <input type="checkbox"/> TRANSMIT ENABLED <input type="checkbox"/> RECEIVED <input type="checkbox"/> TEST DATA
<b>ATTRIBUTES</b> STN ..... NICK NAME ..... ID ..... <div>UNKNOWN</div> MODE1 IFF ..... MODE2 IFF ..... MODE3 IFF ..... MODE4 IFF ..... DI ..... PU/RU ..... 030 DR TYPE ..... <div>SUBSURFACE TRACK</div> NRT ..... <div>NON-REALTIME*</div> CLASS KIND .. <div>NS/UNCLASSIFIED</div> CLASS AMP. . <div>NS</div> POSS. SUB .. <div></div>  <div>GMT OF ACQSTN/OBSRVTN *</div> 20:36 ASW SENSOR <div>NS</div>	<b>LAST REPORT</b> TIMELATE .... 000:00 RPT DTG ..... 161248Z DEC 95 LAT/LONG .... 0505S 00318W GRID POS (NM) ..... CSE (T) ..... 000.0T SPD (KT) ..... 0000.0KT DEPTH ..... AOU TYPE .... ELLIPSE AOU BRG (T) ... 000.0 SMJR (NM) .... 00009 SMNR (NM) .... 00009 SENSOR ..... SOURCE ..... NTDS XREF .....	
<div>SAVE</div> <div>XMIT</div> <div>CANCEL</div>		

\*Abbreviated label.

#### How to Use the NEW SUBSURFACE TRACK REPORT Window:

1. Enter data.
  - Type data, such as NICK NAME.
  - Click on the select button and choose a value, such as ID.
  - Set checkboxes.
2. Save the information. (Or click CANCEL to discard it.)
  - SAVE saves the track.

- XMIT transmits and saves the track.
- 3. Invalid data entered into any field appears in red when SAVE or XMIT is clicked.
  - Correct the data.
  - Click SAVE or XMIT again.
- 4. An alert displays if no numbers in the assigned Track Block are available.
  - Contact the Link Coordinator to adjust the Link Track Block Assignment.

### NEW SUBSURFACE TRACK REPORT Window Fields:

#### *TRACK NUMBERS Box*

The system assigns track numbers when a new track is saved. These fields are view-only. See *Surface Track Report* for a detailed explanation of each field.

#### *RELATED INFORMATION Box*

The RELATED INFORMATION box in this window contains fields that are the same as fields in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

#### *STATUS Box*

The STATUS box in this window is identical to the STATUS box in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

#### *ATTRIBUTES Box*

Many of the fields in the ATTRIBUTES box are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

#### **DR TYPE**

Data Report Type. Type of subsurface track being reported.

#### **NRT**

Indicates if track is being reported in real time or non-real time.

#### **CLASS KIND**

Classification of the track.

#### **CLASS AMP**

Class amplification.

**POSS. SUB**

Confidence level of identifying a track which is a possible submarine.

**(Time Select Button)**

GMT OF ACQSTN/OBSRVTN/EST/COMCNT—Time track was first observed.

CONTACT DURATION—Total continuous contact time.

GMT OF TIME LOST—Time observation was lost.

**ASW SENSOR**

Sensor used to determine track's characteristics.

**DEPTH (QUALITATIVE)**

Relative depth of track, such as Estimated Shallow or Periscope Depth.

**MISSION**

Type of mission, such as Reconnaissance or Escort.

**MISSILE CAP**

Missile capability, or types of missiles for the track.

*LAST REPORT Box*

Many of the fields in the LAST REPORT box are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

**DEPTH**

Depth for the track.

## ASW Bearing

Select ASW BEARING track type and click OK to open the NEW ASW BEARING TRACK REPORT window.

LINK11-A: REAL-WORLD - NEW ASW BEARING TRACK REPORT		
ASW BEARING TRACK		
<b>TRACK NUMBERS</b> LTN ..... FTN ..... CTSX ..... STN ..... JTN ..... PARENT ..... UID .....	<b>RELATED INFORMATION</b> PU/RU 030 has Reporting Responsibility No associated tracks <div style="text-align: center; margin-top: 10px;"> <input type="button" value="TRACK ASSOC"/> <input type="button" value="DELETE"/> </div>	<b>STATUS</b> <input type="checkbox"/> EMERGENCY STATUS <input type="checkbox"/> FORCE TELL STATUS <input type="checkbox"/> SPI <input type="checkbox"/> TRANSMIT ENABLED <input type="checkbox"/> RECEIVED <input type="checkbox"/> TEST DATA
ATTRIBUTES		
<div style="display: flex; justify-content: space-between;"> <div style="width: 55%;">           NICK NAME .....            ID ..... <input type="text" value="NS"/> <input type="button" value="Select"/>            REPORT TYPE ... <input type="text" value="PASSIVE BEARING (AMB*)"/> <input type="button" value="Select"/>            PU/RU ..... 030            ASW CLASS ..... <input type="text" value="NS"/> <input type="button" value="Select"/>            ASW CLASS AMP. <input type="text" value="NS"/> <input type="button" value="Select"/>            SRC FREQ ..... UNKNOWN            BROADBAND .... <input type="text" value="NS"/> <input type="button" value="Select"/>            SPP ..... <input type="text" value="NS"/> <input type="button" value="Select"/>            DOPPLER ..... <input type="text" value="NS"/> <input type="button" value="Select"/>            AB LAYER ..... <input type="text" value="NS"/> <input type="button" value="Select"/>            FREQ 1 ..... UNKNOWN            FREQ 2 ..... UNKNOWN            ASW SENSOR ... <input type="text" value="ACTIVE SONAR"/> <input type="button" value="Select"/>            BEARING DRIFT. <input type="text" value="NS"/> <input type="button" value="Select"/>            BEARING ACC*.. <input type="text" value="NS"/> <input type="button" value="Select"/>            BEARING 1 ..... 0.000            BEARING 2 ..... 0.000            TIME ESTABLISHED 10.01         </div> <div style="width: 40%; border-left: 1px solid black; padding-left: 10px;"> <b>LAST REPORT</b>            TIMELATE .. 000:00            RPT DTG ... 161248Z DEC 95            LAT/LONG .. 0505S 00318W            GRID POS (NM) .....            CSE (T) ..... 000.0            SPD (KT) .... 0000.0            DEPTH .....            AOU TYPE .. ELLIPSE            AOU BRG (T) . 000.0            SMJR (NM) .. 00009            SMNR (NM) .. 00009            SENSOR ...            SOURCE ... NTDS            XREF .....         </div> </div>		
<input type="button" value="SAVE"/> <input type="button" value="XMIT"/> <input type="button" value="CANCEL"/>		

\*Abbreviated label.

#### How to Use the NEW ASW BEARING TRACK REPORT Window:

1. Enter data.
  - Type data, such as NICK NAME.
  - Click the select button and choose a value, such as ID.

- Set checkboxes.
- 2. Save the information. (Or click CANCEL to discard it.)
  - SAVE saves the track.
  - XMIT transmits and saves the track.
- 3. Invalid data entered into any field appears in red when SAVE or XMIT is clicked.
  - Correct the data.
  - Click SAVE or XMIT again.
- 4. An alert displays if no numbers in the assigned Track Block are available.
  - Contact the Link Coordinator to adjust the Link Track Block Assignment.

#### NEW ASW BEARING TRACK REPORT Window Fields:

##### *TRACK NUMBERS Box*

The system assigns track numbers when a new track is saved. These fields are view-only. See *Surface Track Report* for a detailed explanation of each field.

##### *RELATED INFORMATION Box*

The RELATED INFORMATION box in this window contains fields that are the same as fields in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *STATUS Box*

The STATUS box in this window is identical to the STATUS box in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about these fields.

##### *ATTRIBUTES Box*

Many of the fields in the ATTRIBUTES box of the NEW ASW BEARING TRACK REPORT window are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

##### **REPORT TYPE**

Type of ASW Bearing being reported.

##### **ASW CLASS**

Classification of track.

**ASW CLASS AMP**

Classification amplifier.

**SRC FREQ**

Source Acoustic Frequency of the bearing.

**BROADBAND**

Indicates the presence of broadband noise.

**SPP**

Sound Propagation Path used to detect the acoustic track.

**DOPPLER**

Doppler associated with the track.

**AB LAYER**

Indicates if the sonar is above or below the layer.

**FREQ 1**

Two additional associated acoustic frequencies may be reported for an ASW Bearing Track. This displays the first of the associated frequencies.

**FREQ 2**

Second associated frequency.

**ASW SENSOR**

Sensor used to determine the characteristics of the track.

**BEARING DRIFT**

Direction of change (drift) of the track.

**BEARING ACCURACY**

Accuracy, in degrees, of the bearing track. The accuracy is equal to or better than the value displayed in this field.

**BEARING 1**

Bearing of the track.

**BEARING 2**

A second bearing for the track displays if an ambiguous bearing report exists.

**TIME ESTABLISHED**

Time track was first reported.

**AUDIO PRESENCE**

Indicates if audio is present for the track.

**TN ORIGINATOR**

Track number of the unit originating the bearing report. Shown only if the originating unit is not the reporting unit.

**SENSOR DEPTH**

Reported sensor depth in 100-foot increments.

**CONTACT DEPTH**

Depth of contact, such as Estimated shallow or Bottomed.

**RANGE (YDS)**

Distance to reported contact , in 250 yard increments.

**RANGE ACCURACY (MI)**

Range accuracy in five-mile increments.

*LAST REPORT Box*

Many of the fields in the LAST REPORT box are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

**DEPTH**

Depth for the track.

## Electronic Support Message (ESM)

Select ESM track type from the NEW TRACK window and click OK to open the ESM MESSAGE REPORT window.

LINK11-A: REAL-WORLD - NEW ESM MESSAGE REPORT		
ESM TRACK		
<b>TRACK NUMBERS</b> LTN ..... FTN ..... CTSX ..... STN ..... JTN ..... PARENT ..... UID .....	<b>RELATED INFORMATION</b> PU/RU 030 has Reporting Responsibility No associated tracks  <div>TRACK ASSOC</div> <div>DELETE</div>	<b>STATUS</b> <input type="checkbox"/> EMERGENCY STATUS <input type="checkbox"/> FORCE TELL STATUS <input type="checkbox"/> SPI <input type="checkbox"/> TRANSMIT ENABLED <input type="checkbox"/> RECEIVED <input type="checkbox"/> TEST DATA
<b>ATTRIBUTES</b> STN ..... NICK NAME ..... KIND ..... <div>BEARING</div> ID ..... <div>NS</div> MODE 1 IFF ..... MODE 2 IFF ..... MODE 3 IFF ..... MODE 4 IFF ..... DI ..... PU/RU ..... 030 BROAD CLASS ..... <div>NS</div> AMP CHAR ..... <div>NS</div> BEARING ..... 0.000 BEARING ACCURACY ..... <div>NS</div> PLATFORM ..... <div>NS</div> FREQUENCY (Hz) .... 0.000 Hz FREQ RANGE ..... <div>NS</div> JITTER ..... <div>NS</div> SCAN CHAR ..... <div>NS</div> PRF (Hz) ..... NS ANT POLARIZATION .. <div>NS</div> PULSE WIDTH (uSec) . 0000000.0 <div>SCAN PERIOD</div> 000.000 EMITTER NUMBER ... NS PLATFORM NUMBER . NS TIME STALE (minutes) . NS PLAT EVAL CONF. .... NS		<b>LAST REPORT</b> TIMELATE .. 000:00 RPT DTG ... 161248Z DEC 95 LAT/LONG .. 0505S 00318W GRID POS (NM) ..... CSE (T) .... 000.0 SPD (KT) .... 0000.0 ALTITUDE .. ... AOU TYPE .. ELLIPSE AOU BRG (T) . 000.0 SMJR (NM) .. 00009 SMNR (NM) .. 00009 SENSOR ... ..... SOURCE ... NTDS XREF .....
<div>SAVE</div> <div>XMIT</div> <div>CANCEL</div>		

### How to Use the NEW ESM MESSAGE REPORT Window:

1. Enter data.



- Type data, such as NICK NAME.
  - Click the select button and choose a value, such as ID.
  - Set checkboxes.
2. Save the information. (Or click CANCEL to discard it.)
    - SAVE saves the track.
    - XMIT transmits and saves the track.
  3. Invalid data entered into any field appears in red when SAVE or XMIT is clicked.
    - Correct the data.
    - Click SAVE or XMIT again.
  4. An alert displays if no numbers in the assigned Track Block are available.
    - Contact the Link Coordinator to adjust the Link Track Block Assignment.

#### NEW ESM MESSAGE REPORT Window Fields:

##### *TRACK NUMBERS Box*

The system assigns track numbers when a new track is saved. These fields are view-only. See *Surface Track Report* for a detailed explanation of each field.

##### *RELATED INFORMATION Box*

The RELATED INFORMATION box in this window contains fields that are the same as fields in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *STATUS Box*

The STATUS box in this window contains fields that are the same as fields in the STATUS box in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about these fields.

##### *ATTRIBUTES Box*

Many of the fields in the ATTRIBUTES box of the NEW ESM MESSAGE REPORT window are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

##### **KIND**

Kind of report.

**BROAD CLASS**

Broad classification of the emitter.

**AMP CHAR**

Amplifying characteristics of the emitter.

**BEARING**

Bearing of the track.

**BEARING ACCURACY**

Accuracy, in degrees, of the bearing track. The accuracy is equal to or better than the value displayed in this field.

**PLATFORM**

Platform type.

**FREQUENCY (Hz)**

Frequency measured in Hz.

**FREQ RANGE**

Range of frequency.

**JITTER**

Indicates presence of jitter.

**SCAN CHAR**

Scan characterization.

**PRF (Hz)**

Pulse Repetition Frequency measured in Hz.

**ANT POLARIZATION**

Antenna polarization.

**PULSE WIDTH (uSec)**

Pulse width measured in microseconds.

**SCAN PERIOD/SCAN RATE**

Antenna scan information. Either seconds per scan (period) or frequency range (rate).

**EMITTER NUMBER**

Number indicating a specific emitter.

**PLATFORM NUMBER**

Number indicating the emitter platform.

**TIME STALE**

Time since report was updated.

**PLAT EVAL CONF**

Platform Evaluation Confidence—level of confidence that the attribute values displayed are accurate.

**CONFIDENCE**

Degree of confidence of the reported emitter evaluation.

*LAST REPORT Box*

The LAST REPORT box is identical to the LAST REPORT box in the NEW SURFACE TRACK REPORT window and is described in *Surface Track Report*.

## Area of Probability (AOP)

Select AREA OF PROBABILITY track type from the NEW TRACK window and click OK to open the NEW AREA OF PROBABILITY REPORT window.

LINK11-A: REAL-WORLD - NEW AREA OF PROBABILITY REPORT		
AREA OF PROBABILITY TRACK		
<div style="border: 1px solid black; padding: 5px;"> <b>TRACK NUMBERS</b>            LTN .....            FTN .....            CTSX .....            STN .....            JTN .....            PARENT .....            UID .....         </div>	<div style="border: 1px solid black; padding: 5px;"> <b>RELATED INFORMATION</b>            PU/RU 030 has Reporting Responsibility            No associated tracks   <div style="text-align: center;"> <input type="button" value="TRACK ASSOC"/> <input type="button" value="DELETE"/> </div> </div>	<div style="border: 1px solid black; padding: 5px;"> <b>STATUS</b>   <input type="checkbox"/> SPI  <input type="checkbox"/> TRANSMIT ENABLED  <input type="checkbox"/> RECEIVED         </div>
ATTRIBUTES		
<div style="border: 1px solid black; padding: 5px;">           STN .....            NICK NAME .....            CATEGORY .. <input type="text" value="NS"/> <input type="button" value="☐"/>            MODE1 IFF ... ..            MODE2 IFF ... ..            MODE3 IFF ... ..            MODE4 IFF ... ..            PU/RU ..... 030            SOURCE..... <input type="text" value="ESTIMATED BY RU*"/> <input type="button" value="☐"/>            RELATED TN ..... ▼            PROBABILITY FACTOR <input type="text" value="EXCELLENT 70%-*"/> <input type="button" value="☐"/>            TIME OF UPDATE 00:00         </div>		<div style="border: 1px solid black; padding: 5px;"> <b>LAST REPORT</b>             TIMELATE .. 000:09            RPT DTG ... 161248Z DEC 95            LAT/LONG .. 0505S 00318W            GRID POS (NM) .....            CSE (T) .... 000.0            SPD (KT) .... 0000.0            ALTITUDE .. .....            AOU TYPE .. <input type="text" value="ELLIPSE"/> <input type="button" value="☐"/>            AOU BRG (T) . ....            SMJR (NM) .. 00009            SMNR (NM) .. 00009            SENSOR ... ..            SOURCE ... NTDS            XREF .....         </div>
<input type="button" value="SAVE"/> <input type="button" value="XMIT"/> <input type="button" value="CANCEL"/>		

\* Abbreviated label.

### How to Use the NEW AREA OF PROBABILITY REPORT Window:

1. Enter data.
  - Type data, such as NICK NAME.
  - Click the select button and choose a value, such as CATEGORY.
  - Set checkboxes.
2. Save the information. (Or click CANCEL to discard it.)
  - SAVE saves the track.
  - XMIT transmits and saves the track.

3. Invalid data entered into any field appears in red when SAVE or XMIT is clicked.
  - Correct the data.
  - Click SAVE or XMIT again.
4. An alert displays if no numbers in the assigned Track Block are available.
  - Contact the Link Coordinator to adjust the Link Track Block Assignment.

## NEW AREA OF PROBABILITY REPORT Window Fields:

### *TRACK NUMBERS Box*

The system assigns track numbers when a new track is saved. These fields are view-only. See *Surface Track Report* for a detailed explanation of each field.

### *RELATED INFORMATION Box*

The RELATED INFORMATION box in this window contains fields that are the same as fields in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

### *STATUS Box*

The options in the STATUS box are inactive.

### *ATTRIBUTES Box*

Many of the fields in the ATTRIBUTES box of the NEW AREA OF PROBABILITY REPORT window are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

### **CATEGORY**

Track category.

### **SOURCE**

Source of the report.

**RELATED TN**

Related local Link-11 track number for a Link track, point, bearing, or fix.

**TIME OF UPDATE**

Time the last report was received for this track.

**PROBABILITY FACTOR**

Level of confidence that track is within the area of probability.

**EXPANSION/CONTRACTION**

Indicates if Area of Probability is expanding or contracting.

**X/C RATE (KTS)**

Rate, in knots, at which the Area of Probability is expanding or contracting.

*LAST REPORT Box*

Many of the fields in the LAST REPORT box are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

**AOU TYPE**

Area of uncertainty—ELLIPSE or BBOX (Bearing Box).

ELLIPSE—associated fields are SMJR (semi-major) and SMNR (semi-minor) axes.

BBOX—associated fields are LEN (length) and H-WIDTH (half-width).

## Sonobuoy

Select SONOBUOY from the NEW TRACK window and click OK to open the NEW SONOBUOY TRACK REPORT window.

NEW SONOBUOY TRACK REPORT		
<b>TRACK NUMBERS</b> LTN ..... FTN ..... CTSX ..... STN ..... JTN ..... PARENT ..... UID .....	<b>RELATED INFORMATION</b> PU/RU 030 has Reporting Responsibility No associated tracks  <div>DELETE</div>	<b>STATUS</b> <input type="checkbox"/> EMERGENCY STATUS <input type="checkbox"/> FORCE TELL STATUS
<div> <div> <b>ATTRIBUTES</b>            STN .....            NICK NAME ..            ID ..... <div>UNKNOWN</div>            REPORT TYPE . SONOBUOY            PU/RU .....            DEPTH ..... <div>NO STATEMENT</div>            CHANNEL NUMBER NS            CONTACT STATUS <div>NO STATEMENT</div>            TRANSDUCER <div>NO STATEMENT</div>            TIME REMAINING <div>ZERO MINUTES</div>    <div>GMT OF ACQSTN/OBSRVTN *</div> .....           </div> <div> <b>LAST REPORT</b>            TIMELATE .. 000:09            RPT DTG ... 161248Z DEC 94            LAT/LONG .. 0505S 00318W            GRID POS (NM) .....            CSE ..... 000.0T            SPD ..... 0000.0KT            ALTITUDE ..            AOU TYPE .. ELLIPSE            AOU BRG(T) . 000.0            SMJR(NM) .. .00009            SMNR(NM) .. .00009            SENSOR ...            SOURCE ... NTDS            XREF ..... L11A           </div> </div>		
<div> <div>SAVE</div> <div>XMIT</div> <div>CANCEL</div> </div>		

\* Abbreviated label.

### How to Use the NEW SONOBUOY TRACK REPORT Window:

- Enter data.
  - Type data, such as NICK NAME.
  - Click the select button and choose a value, such as ID.
  - Set checkboxes.
- Save the information. (Or click CANCEL to discard it.)
  - SAVE saves the track.
  - XMIT transmits and saves the track.

3. Invalid data entered into any field appears in red when SAVE or XMIT is clicked.
  - Correct the data.
  - Click SAVE or XMIT again.
4. An alert displays if no numbers in the assigned Track Block are available.
  - Contact the Link Coordinator to adjust the Link Track Block Assignment.

#### **NEW SONOBUOY TRACK REPORT Window Fields:**

##### *TRACK NUMBERS Box*

The system assigns track numbers when a new track is saved. These fields are view-only. See *Surface Track Report* for a detailed explanation of each field.

##### *RELATED INFORMATION Box*

The RELATED INFORMATION box in this window contains fields that are the same as fields in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *STATUS Box*

The STATUS box in this window contains fields that are the same as fields in the STATUS box in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *ATTRIBUTES Box*

Many of the fields in the ATTRIBUTES box are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

##### **REPORT TYPE**

Sonobuoy report type. This field is view-only.

##### **DEPTH**

Depth sonobuoy is suspended below surface.

##### **CHANNEL NUMBER**

Sonobuoy channel number.

##### **CONTACT STATUS**

Indicates active or inactive sonobuoy.



**TRANSDUCER**

Type of sonobuoy.

**TIME REMAINING**

Time remaining before sonobuoy expires.

**(Time Select Button)**

GMT OF ACQSTN/OBSRVTN/EST/COMCNT—time track was first observed.

GMT OF TIME LOST—time observation was lost.

**TIME LOST**

Elapsed time since sonobuoy contact was lost (from 5 to 360 minutes).

**CALIBRATION STATUS**

Calibration status of the sonobuoy, either Calibrated or No Statement.

*LAST REPORT Box*

The LAST REPORT box is identical to the LAST REPORT box in the NEW SURFACE TRACK REPORT window and is described in *Surface Track Report*.

## Special Point

Select SPECIAL POINT from the NEW TRACK window and click OK to open the NEW SPECIAL POINT REPORT window.

LINK11-A:REAL-WORLD - NEW SPECIAL POINT REPORT		
SPECIAL POINT TRACK		
<b>TRACK NUMBERS</b> LTN ..... FTN ..... CTSX ..... STN ..... JTN ..... PARENT ..... UID .....	<b>RELATED INFORMATION</b> PU/RU 030 has Reporting Responsibility No associated tracks  <input type="button" value="TRACK ASSOC"/> <input type="button" value="DELETE"/>	<b>STATUS</b> <input type="checkbox"/> EMERGENCY STATUS <input type="checkbox"/> FORCE TELL STATUS <input type="checkbox"/> SPI <input type="checkbox"/> TRANSMIT ENABLED <input type="checkbox"/> RECEIVED <input type="checkbox"/> TEST DATA
<b>ATTRIBUTES</b> STN ..... NICK NAME . PT TYPE ..... <input type="button" value="HAZARD"/> <input type="button" value="GROUND ZERO"/> PT AMPLIFY .. PU/RU ..... 030 <input type="button" value="GMT OF INITIAL OBSERVATION"/> 00:00		<b>LAST REPORT</b> TIMELATE .. 000:09 RPT DTG ... 161248Z DEC 95 LAT/LONG .. 0505S 00318W GRID POS (NM) ..... CSE (T) ..... 000.0 SPD (KT) .... 0000.0 ALT/DEPTH . AOU TYPE .. ELLIPSE AOU BRG (T) . 000.0 SMJR (NM) .. 00009 SMNR (NM) .. 00009 SENSOR ... SOURCE ... NTDS XREF .....
<input type="button" value="SAVE"/> <input type="button" value="XMIT"/> <input type="button" value="CANCEL"/>		

### How to Use the NEW SPECIAL POINT REPORT Window:

- Enter data.
  - Type data, such as NICK NAME.
  - Click the select button and choose a value, such as PT TYPE.
  - Set checkboxes.
- Save the information. (Or click CANCEL to discard it.)
  - SAVE saves the track.
  - XMIT transmits and saves the track.
- Invalid data entered into any field appears in red when SAVE or XMIT is clicked.
  - Correct the data.

- Click SAVE or XMIT again.
4. An alert displays if no numbers in the assigned Track Block are available.
- Contact the Link Coordinator to adjust the Link Track Block Assignment.

#### NEW SPECIAL POINT REPORT Window Fields:

##### *TRACK NUMBERS Box*

The system assigns track numbers when a new track is saved. These fields are view-only. See *Surface Track Report* for a detailed explanation of each field.

##### *RELATED INFORMATION Box*

The RELATED INFORMATION box in this window contains fields that are the same as fields in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *STATUS Box*

The STATUS box in this window is identical to the STATUS box in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *ATTRIBUTES Box*

Many of the fields in the ATTRIBUTES box are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

##### **PT TYPE**

Point type.

##### **PT AMPLIFY**

Amplifies point type.

##### **(Time Select Button)**

GMT OF INITIAL OBSERVATION—time track was first observed.

GMT OF OBSERVATION/INFORMATION—time of updated information.

##### *LAST REPORT Box*

Many fields in the LAST REPORT box are identical to those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

**ALT/DEPTH**

Altitude or depth of the track.

## Pointer

Select POINTER track type from the NEW TRACK window and click OK to open the NEW POINTER TRACK REPORT window.

LINK11-A: REAL-WORLD - NEW POINTER TRACK REPORT		
POINTER TRACK		
<b>TRACK NUMBERS</b> LTN ..... FTN ..... CTSX ..... STN ..... JTN ..... PARENT ..... UID .....	<b>RELATED INFORMATION</b> PU/RU 030 has Reporting Responsibility No associated tracks  <div> <div>TRACK ASSOC</div> <div>DELETE</div> </div>	<b>STATUS</b>  <input type="checkbox"/> TRANSMIT ENABLED <input type="checkbox"/> RECEIVED
<b>ATTRIBUTES</b>  NICK NAME ... ..... ORIGINATOR .. 30 ADDRESSEE .. 10 <input checked="" type="checkbox"/> OPERATOR ... <div>WEAPONS <input type="button" value=""/></div>		<b>LAST REPORT</b>  TIMELATE .. 000:09 RPT DTG ... 161248Z DEC 95 LAT/LONG .. 0505S 00318W GRID POS (NM) ..... CSE (T) .... 000.0 SPD (KT) .... 0000.0 ALTITUDE .. ..... AOU TYPE .. ELLIPSE AOU BRG (T) . 000.0 SMJR (NM) .. 00009 SMNR (NM) .. 00009 SENSOR ... ..... SOURCE ... ..... XREF ..... NTDS
<div>SAVE</div> <div>XMIT</div> <div>CANCEL</div>		

### How to Use the NEW POINTER TRACK REPORT Window:

1. Enter data.
  - Type data, such as NICK NAME.
  - Click the select button and choose a value, such as ORIGINATOR.

- Set checkboxes.
- 2. Save the information. (Or click CANCEL to discard it.)
  - SAVE saves the track.
  - XMIT transmits and saves the track.
- 3. Invalid data entered into any field appears in red when SAVE or XMIT is clicked.
  - Correct the data.
  - Click SAVE or XMIT again.
- 4. An alert displays if no numbers in the assigned Track Block are available.
  - Contact the Link Coordinator to adjust the Link Track Block Assignment.

#### NEW POINTER TRACK REPORT Window Fields:

##### *TRACK NUMBERS Box*

The system assigns track numbers when a new track is saved. These fields are view-only. See *Surface Track Report* for a detailed explanation of each field.

##### *RELATED INFORMATION Box*

The RELATED INFORMATION box in this window contains fields that are the same as fields in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *STATUS Box*

The options in the STATUS box are inactive.

##### *ATTRIBUTES Box*

###### **NICK NAME**

Local name for the track. This name is not transmitted to other locations.

###### **ORIGINATOR**

Unit address of pointer where report originated. This field is view-only. It is set to owntrack's STN.

###### **ADDRESSEE**

Unit address to receive the pointer. The list of available PUs is generated by the PUs currently reporting on the network.

###### **OPERATOR**

Specific operator within a unit to receive the pointer.

### LAST REPORT Box

The LAST REPORT box is identical to the LAST REPORT box in the NEW SURFACE TRACK REPORT window and is described in *Surface Track Report*.

## NOTACK

Select NOTACK track type from the NEW TRACK window and click OK to open the NEW NOTACK TRACK REPORT window.

LINK11-A: REAL-WORLD - NEW NOTACK TRACK REPORT		
NOTACK REPORT		
<b>TRACK NUMBERS</b> LTN ..... FTN ..... CTSX ..... STN ..... JTN ..... PARENT ..... UID .....	<b>RELATED INFORMATION</b> PU/RU 030 has Reporting Responsibility No associated tracks  <div>TRACK ASSOC</div> <div>DELETE</div>	<b>STATUS</b> <input type="checkbox"/> EMERGENCY STATUS <input type="checkbox"/> FORCE TELL STATUS <input type="checkbox"/> SPI <input type="checkbox"/> TRANSMIT ENABLED <input type="checkbox"/> RECEIVED <input type="checkbox"/> TEST DATA
<b>ATTRIBUTES</b> STN ..... NICK NAME ..... ID ..... <div>UNKNOWN</div> RADIUS ..... <div>10DM</div> START ..... 00:00 DURATION ... <div>1 HOUR</div>		<b>LAST REPORT</b> TIMELATE .. 000:09 RPT DTG ... 161248Z DEC 95 LAT/LONG .. 0505S 00318W GRID POS (NM) ..... CSE (T) .... 000.0 SPD (KT) .... 0000.0 ALTITUDE .. ..... AOU TYPE .. ELLIPSE AOU BRG (T) . 000.0 SMJR (NM) .. 00009 SMNR (NM) .. 00009 SENSOR ... ..... SOURCE ... ..... XREF ..... NTDS
<div>SAVE</div> <div>XMIT</div> <div>CANCEL</div>		

### How to Use the NEW NOTACK TRACK REPORT Window:

1. Enter data.
  - Type data, such as NICK NAME.

- Click the select button and choose a value, such as ID.
  - Set checkboxes.
2. Save the information. (Or click CANCEL to discard it.)
    - SAVE saves the track.
    - XMIT transmits and saves the track.
  3. Invalid data entered into any field appears in red when SAVE or XMIT is clicked.
    - Correct the data.
    - Click SAVE or XMIT again.
  4. An alert displays if no numbers in the assigned Track Block are available.
    - Contact the Link Coordinator to adjust the Link Track Block Assignment.

#### NEW NOTACK TRACK REPORT Window Fields:

##### *TRACK NUMBERS Box*

The system assigns track numbers when a new track is saved. These fields are view-only. See *Surface Track Report* for a detailed explanation of each field.

##### *RELATED INFORMATION Box*

The RELATED INFORMATION box in this window contains fields that are the same as fields in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *STATUS Box*

The STATUS box in this window is identical to the STATUS box in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *ATTRIBUTES Box*

Many of the fields in the ATTRIBUTES box are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

##### **RADIUS**

Radius of the notack area.

##### **START**

Start time of notack area designation.

**DURATION**

Total time of notack area designation.

*LAST REPORT Box*

The LAST REPORT box is identical to the LAST REPORT box in the NEW SURFACE TRACK REPORT window and is described in *Surface Track Report*.

## Acoustic Bearing

Select ACOUSTIC BEARING track type from the NEW TRACK window and click OK to open the NEW ACOUSTIC BEARING TRACK REPORT window.

NEW ACOUSTIC BEARING TRACK REPORT		
<b>TRACK NUMBERS</b> LTN ..... FTN ..... CTSX ..... STN ..... JTN ..... PARENT ..... UID .....	<b>RELATED INFORMATION</b> PU/RU has Reporting Responsibility. No associated tracks  <div>DELETE</div>	<b>STATUS</b> <input type="checkbox"/> EMERGENCY STATUS <input type="checkbox"/> FORCE TELL STATUS <input type="checkbox"/> SPI <input type="checkbox"/> TRANSMIT ENABLED <input type="checkbox"/> RECEIVED
<b>ATTRIBUTES</b> STN ..... NICK NAME .. ID ..... <div>NO STATEMENT*</div> PU/RU ..... BEARING 1 .... TIME ESTABLISHED ....	<b>LAST REPORT</b> TIMELATE .. 000:09 RPT DTG ... 161248Z DEC 94 LAT/LONG .. 0505S 00318W GRID POS (NM) ..... CSE ..... 000.0T SPD ..... 0000.0KT DEPTH ..... AOU TYPE .. LOB AOU BRG (T) . .... ERR (DEG) .. .... RNG (NM)) ... .... SENSOR ... .... SOURCE ... NTDS XREF ..... L11A	
<div> <div>◀</div> <div></div> <div>▶</div> </div>		
<div> <div>SAVE</div> <div>XMIT</div> <div>CANCEL</div> </div>		



\* Abbreviated label.

### How to Use the NEW ACOUSTIC BEARING TRACK REPORT Window:

1. Enter data.
  - Type data, such as NICK NAME.
  - Click the select button and choose a value, such as ID.
  - Set checkboxes.
2. Save the information. (Or click CANCEL to discard it.)
  - SAVE saves the track.
  - XMIT transmits and saves the track.
3. Invalid data entered into any field appears in red when SAVE or XMIT is clicked.
  - Correct the data.
  - Click SAVE or XMIT again.
4. An alert displays if no numbers in the assigned Track Block are available.
  - Contact the Link Coordinator to adjust the Link Track Block Assignment.

### NEW ACOUSTIC BEARING TRACK REPORT Window Fields:

#### *TRACK NUMBERS Box*

The system assigns track numbers when a new track is saved. These fields are view-only. See *Surface Track Report* for a detailed explanation of each field.

#### *RELATED INFORMATION Box*

The RELATED INFORMATION box in this window contains fields that are the same as fields in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

#### *STATUS Box*

The STATUS box in this window contains fields that are the same as fields in the STATUS box in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

#### *ATTRIBUTES Box*

Many of the fields in the ATTRIBUTES box are the same as those in the NEW

SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

**BEARING 1**

AOU bearing.

**TIME ESTABLISHED**

Time track was established.

**ERR**

AOU bearing error.

**RNG**

AOU bearing range.

*LAST REPORT Box*

Many of the fields in the LAST REPORT box are the same as the LAST REPORT fields in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

**DEPTH**

Depth for the track.

## Air

Select AIR track type from the NEW TRACK window and click OK to open the NEW AIR TRACK REPORT window.

NEW AIR TRACK REPORT		
<b>TRACK NUMBERS</b> LTN ..... FTN ..... CTSX ..... STN ..... JTN ..... PARENT ..... UID .....	<b>RELATED INFORMATION</b> PU/RU 030 has Reporting Responsibility No associated tracks  <div>TRACK ASSOC</div> <div>DELETE</div>	<b>STATUS</b> <input type="checkbox"/> EMERGENCY STATUS <input type="checkbox"/> FORCE TELL STATUS <input type="checkbox"/> SPI <input type="checkbox"/> TRANSMIT ENABLED <input type="checkbox"/> RECEIVED
<b>ATTRIBUTES</b> STN ..... NICK NAME ..... ID ..... <div>UNKNOWN</div> PRI AMP ..... <div>PENDING *</div> ID AMP ..... <div>NO STATEMENT</div> MODE1 IFF ..... MODE2 IFF ..... MODE3 IFF ..... MODE4 IFF ..... <div>...</div> DI ..... 0071 PU/RU ..... TQ ..... <div>NON-REAL-TIME *</div> RAID SIZE ..... <div>UNESTIMATED</div> CONTROLLING TN .. <div>NONE</div> OBSERVE TIME .... 14:59 HEIGHT SOURCE ... <div>NO STATEMENT</div>		<b>LAST REPORT</b> TIMELATE .. 000:09 RPT DTG ... 161248Z DEC 95 LAT/LONG .. 0505S 00318W GRID POS (NM) ..... CSE(T) .... 000.0 SPD(KT) .... 0000.0 ALTITUDE .. ..... AOU TYPE .. ELLIPSE AOU BRG(T) . 000.0 SMJR(NM) .. 00009 SMNR(NM) .. 00009 SENSOR ... ..... SOURCE ... NTDS XREF ..... L11A
<div> <div>◀</div> <div></div> <div>▶</div> </div>		
<div>SAVE</div> <div>XMIT</div> <div>CANCEL</div>		

\* Abbreviated label.

### How to Use the NEW AIR TRACK REPORT Window:

- Enter data.
  - Type data, such as NICK NAME.
  - Click the select button and choose a value, such as ID.
  - Set checkboxes.
- Save the information. (Or click CANCEL to discard it.)
  - SAVE saves the track.
  - XMIT transmits and saves the track.

3. Invalid data entered into any field appears in red when SAVE or XMIT is clicked.
  - Correct the data.
  - Click SAVE or XMIT again.
4. An alert displays if no numbers in the assigned Track Block are available.
  - Contact the Link Coordinator to adjust the Link Track Block Assignment.

#### **NEW AIR TRACK REPORT Window Fields:**

##### *TRACK NUMBERS Box*

The system assigns track numbers when a new track is saved. These fields are view-only. See *Surface Track Report* for a detailed explanation of each field.

##### *RELATED INFORMATION Box*

The RELATED INFORMATION box in this window contains fields that are the same as fields in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *STATUS Box*

The STATUS box in this window contains fields that are the same as fields in the STATUS box in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *ATTRIBUTES Box*

Many of the fields in the ATTRIBUTES box are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

##### **CONTROLLING TN**

Track in control of aircraft.

##### **HEIGHT SOURCE**

Source of height report.

##### *LAST REPORT Box*

Many of the fields in the LAST REPORT box are the same as the LAST REPORT fields in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

**ALTITUDE**  
Altitude for the track.

**ASW Tactical Point**

Select ASW TACTICAL POINT track type from the NEW TRACK window and click OK to open NEW ASW TACTICAL POINT TRACK REPORT.

LINK11-A: REAL-WORLD-NEW ASW TACTICAL POINT TRACK REPORT

ASW TACTICAL POINT TRACK

TRACK NUMBERS

LTN .....  
FTN .....  
CTSX .....  
STN .....  
JTN .....  
PARENT .....  
UID .....

RELATED INFORMATION

PU/RU 030 has Reporting Responsibility  
No associated tracks

TRACK ASSOCDELETE

STATUS

☐ EMERGENCY STATUS  
☐ FORCE TELL STATUS  
☐ SPI  
☐ TRANSMIT ENABLED  
☐ RECEIVED  
☐ TEST DATA

ATTRIBUTES

STN .....  
NICK NAME .....  
ID ..... NS  
MODE1 IFF .....  
MODE2 IFF .....  
MODE3 IFF .....  
MODE4 IFF .....  
DI .....  
PU/RU ..... 030  
NRT ..... NS  
ASWPT TYPE ..... NS  
CLASS KIND ..... NS  
CLASS AMP ..... NS  
POSS. SUB ..... NS  
GMT OFACQSTN/OBSVTN/EST\* .....

LAST REPORT

TIMELATE .. 000:00  
RPT DTG ... 161248Z DEC 95  
LAT/LONG .. 0505S 00318W  
GRID POS(NM) .....  
CSE (T) .... 000.0  
SPD (KT) ... 0000.0  
DEPTH .....  
AOU TYPE .. ELLIPSE  
AOU BRG (T) .000.0  
SMJR (NM) .. 00009  
SMNR (NM) .. 00009  
SENSOR ... ..  
SOURCE ... NTDS  
XREF .....

SAVEXMITCANCEL

\* Abbreviated label.

**How to Use the NEW ASW TACTICAL POINT TRACK REPORT Window:**

1. Enter data.

Link-11 2.3.0.0:SUM1.0 4/14/97

- Type data, such as NICK NAME.
  - Click the select button and choose a value, such as ID.
  - Set checkboxes.
2. Save the information. (Or click CANCEL to discard it.)
    - SAVE saves the track.
    - XMIT transmits and saves the track.
  3. Invalid data entered into any field appears in red when SAVE or XMIT is clicked.
    - Correct the data.
    - Click SAVE or XMIT again.
  4. An alert displays if no numbers in the assigned Track Block are available.
    - Contact the Link Coordinator to adjust the Link Track Block Assignment.

#### **NEW ASW TACTICAL POINT TRACK REPORT Window Fields:**

##### *TRACK NUMBERS Box*

The system assigns track numbers when a new track is saved. These fields are view-only. See *Surface Track Report* for a detailed explanation of each field.

##### *RELATED INFORMATION Box*

The RELATED INFORMATION box in this window contains fields that are the same as fields in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *STATUS Box*

The STATUS box in this window contains fields that are the same as fields in the STATUS box in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

##### *ATTRIBUTES Box*

Many of the fields in the ATTRIBUTES box are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

##### **NRT**

Indicates if track is being reported in real time or non-real time.

**ASW PT TYPE**

Type of ASW point.

**CLASS KIND**

Classification of the track.

**CLASS AMP**

Class amplification.

**POSS. SUB**

Confidence level of identifying a track which is a possible submarine.

**(Time Select Button)**

GMT OF ACQSTN/OBSRVTN/EST/COMCNT—time track was first observed.

GMT OF TIME LOST—time observation was lost.

**ASW SENSOR**

Type of ASW sensor.

*LAST REPORT Box*

The LAST REPORT box is identical to the LAST REPORT box in the NEW SURFACE TRACK REPORT window and is described in *Surface Track Report*.

## NEW TRACK Pop-up Menus

The following options are on a pop-up menu in each NEW TRACK window.

**Active options:**

These options are explained in detail in the Edit section of the *Software User's Manual, Unified Build (TMS/UCP)*.

- > CENTER—Center the tactical display on the selected track.
- > EXIT—Close the window.
- > PRINT—Print a hardcopy summary of track database information for the selected track.
- > REQUEST NATO TRACK NUMBER UPDATE—Request update of NATO track number.

- > SAVE—Save changes to the track.
- > XMIT—Transmit the track.

**Inactive options:**

CHANGE CATEGORY, DECORRELATE LOCAL/REMOTE TRK, DELETE, EDIT, EMERGENCY ON/OFF, FORCE TELL ON/OFF, GO TO PARENT, HELP, NEXT, NU TRK, PREVIOUS, REQUEST IFF UPDATE, SEND CLEAR IFF, SEND CLEAR SPECIAL CODE, STOP XMIT, TAKE INTO COMMON STORES (REAL TIME), and TAKE INTO COMMON STORES (NON-REAL TIME).



## Edit Link Track

Use the EDIT LINK TRACK option to modify data for a selected track.

### How to Use this Option:

1. Select a track to edit using one of the methods described below.
2. The VIEW window for the track opens.
3. Click EDIT from the VIEW window to open the EDIT window for the track. (Tracks received from other Participating Units (PUs) may be viewed but not edited.)

> To select tracks to edit:

- Highlight one track on the tactical display and select EDIT LINK TRACK.
- Double-click on a track on the tactical display.
- Highlight more than one track on the tactical display and select EDIT LINK TRACK to display the SELECT LINK TRACK TO EDIT window.
  - Highlight one track in the scroll list.
  - Click OK.
- Select EDIT LINK TRACK with no tracks highlighted to open the DATABASE SEARCH window. This window is described in the Search section of the *Software User's Manual, Unified Build (TMS/UCP)*.

SELECT LINK TRACKS TO EDIT																
TRACK NAME	LTN	STN	FTN	PARENT	PIF	FLAG	CAT	THRT	TYPE	HULL	SOURCE	SENSOR	BRG	RNG	ALRT	TLATE
.....	T4437	....	....	....	....	..	UNK	UNK	ALRT	....	RG	NAV	022	5028	...	000:22
ABRAMS	T4007	....	....	....	5020	UF	AIR	FRD	....	....	RG	NTDS	102	2665	...	000:21
CHARLESTON	T4010	....	....	....	5025	UU	AIR	UNK	F-14	....	RG	NTDS	105	2871	HIT	000:15

## View and Edit Windows

The VIEW and EDIT windows for each track type are similar to the new track

window for that track type.

- Fields in the VIEW window cannot be edited.
- Additional fields appear in some VIEW windows (described in *Additional VIEW Window Fields*).
- Click EDIT from the VIEW window to open the EDIT window.
  - Fields can be modified as described in the NEW LINK TRACK section.

### ***Additional VIEW Window Fields***

#### ***WEAPON STATUS Box***

Displays weapon status set in WEAPON STATUS option.

#### ***TRACK INTELLIGENCE Box***

##### **NATION/ALLIANCE**

Country affiliation.

##### **GENERAL TYPE**

Amplification of reported category.

##### **SPECIFIC TYPE**

Amplification of general type.

##### **MISSION**

Type of mission.

##### **CURRENT ACTIVITY**

Action currently performing.

##### **OPERATIONAL STATUS**

Weapons or facility status.

##### **SECONDARY TN**

Track number of mission object.

#### ***ATTRIBUTES Box***

Many of the fields in the ATTRIBUTES box are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

##### **ALTITUDE FOR WATCH**

Best altitude for radar watch.

**ASW AIRCRAFT TYPE**

Type of ASW aircraft.

**CATEGORY**

Track category.

**FUEL**

Increments of burnable fuel aboard aircraft.

**Inventory Fields**

Number of useable weapons, including:

DEPTH BOMB INV (CONV)

DEPTH BOMB INV (SPCL)

TORPEDO INV (CONV)

TORPEDO INV (SPCL)

MISSILE INV (CONV))

MISSILE INV (SPCL)

ROCKET INV

SONOBUOY INV (ACTIVE))

SONOBUOY INV (PASSIVE)

**POINT**

Type of point.

**POINT AMP**

Amplifying characteristics of the point.

**RECEIVE QUALITY**

Receive quality for the track.

**Sensor Status Fields**

Status of various sensors, either OPERATIONAL or NOT OPERABLE.

Sensors include:

RADAR

INFRA RED

LOFAR

MAD

SEARCH LIGHT

LLTV

DIFAR

SONOBUOY RECEIVER

RECORDER 1

RECORDER 2

RECORDER 3

RECORDER 4

SONAR

DICASS

CASS

ADP 1

ADP 2

**TIME REMAINING**

Time remaining until aircraft is due to depart.

**TIME TO BINGO**

Time to return to base.

**UNIT**

Participating unit type.

**Weapons Capability Fields**

Fields that indicate weapons capability include:

ALL ASPECT ANGLE

MULTIPLE INTERCEPT

NUCLEAR CAPABLE

ORDINANCE

REAR ASPECT

## VIEW WINDOW Pop-up Menus

The following options are available in a pop-up menu in each VIEW window.

**Active options:**

- > CENTER—Center the tactical display on the selected track.
- > DELETE—Delete the track.
- > EDIT—Open the EDIT window for the track.

- > EMERGENCY ON/OFF—Toggle EMERGENCY status checkbox on or off.
- > EXIT—Close the window and exit the option.
- > FORCE TELL ON/OFF—Toggle FORCE TELL status checkbox on or off.
- > NU-TRK—Create a platform track from the Link track.
- > PRINT—Print a hardcopy summary of track database information for the selected track.
- > REQUEST 19-BIT TRACK NUMBER UPDATE—Request update of 19-bit track number.
- > SEND CLEAR IFF—Clear IFF values to zero and transmit to other PUs.
  1. Toggle checkboxes ON for each IFF mode to be cleared.
  2. Click OK to clear and transmit or CANCEL to discard change.
- > SEND CLEAR SPECIAL CODE—Clear DI, also known as Special Code.
- > TAKE INTO COMMON STORES (NON-REAL TIME)—Bring track into local stores to edit information.

**Inactive options:**

CHANGE CATEGORY, DECORRELATE LOCAL/REMOTE TRK, GO TO PARENT, HELP, NEXT, PREVIOUS, REQUEST IFF UPDATE, REQUEST 19-BIT TN UPDATE, REQUEST NATO TRACK NUMBER UPDATE, SAVE, STOP XMIT, TAKE INTO COMMON STORES (REAL TIME), and XMIT.

## **EDIT WINDOW Pop-up Menus**

The following options are available in a pop-up menu in each EDIT window.

**Active options:**

- > CENTER—Center the tactical display on the selected track.

- > **CHANGE CATEGORY** —Change category from Air to Surface or from Surface to Air *only*.
- > **EXIT**—Close the window and exit the option.
- > **NEXT**—View next EDIT window (when multiple tracks are selected).
- > **NU-TRK/GO TO PARENT**—Create a platform track from the Link track, or go to the parent track EDIT window.
- > **PREVIOUS**—View previous EDIT window (when multiple tracks are selected).
- > **PRINT**—Print a hardcopy summary of track database information for the selected track.
- > **REQUEST NATO TRACK NUMBER UPDATE**—Request update of NATO track number.
- > **SAVE**—Save changes to track.
- > **STOP XMIT**—Stop transmitting track.

**Inactive options:**

DECORRELATE LOCAL/REMOTE TRK, DELETE, EDIT, EMERGENCY ON/OFF, FORCE TELL ON/OFF, GO TO PARENT, HELP, REQUEST 19-BIT TRACK NUMBER UPDATE, REQUEST IFF UPDATE, SEND CLEAR IFF, SEND CLEAR SPECIAL CODE, TAKE INTO COMMON STORES (REAL TIME), TAKE INTO COMMON STORES (NON-REAL TIME), and XMIT.

## **Electronic Control Message (ECM) INTERCEPT REPORT**

To view information about a received ECM track, open the ECM INTERCEPT REPORT window as described in *Select Tracks to Edit*.

VIEW ECM INTERCEPT REPORT		
<b>TRACK NUMBERS</b> LTN ..... FTN ..... CTSX ..... STN ..... JTN ..... PARENT ..... UID .....	<b>RELATED INFORMATION</b> PU/RU 030 has Reporting Responsibility No associated tracks  <input type="button" value="TRACK ASSOC"/> <input type="button" value="DELETE"/>	<b>STATUS</b> <input type="checkbox"/> EMERGENCY STATUS <input type="checkbox"/> FORCE TELL STATUS <input type="checkbox"/> SPI <input type="checkbox"/> TRANSMIT ENABLED <input type="checkbox"/> RECEIVED
<b>ATTRIBUTES</b> NICK NAME ..... ID ..... MODE1 IFF ..... MODE2 IFF ..... MODE3 IFF ..... MODE4 IFF ..... DI ..... PU/RU ..... 0071 BROAD CLASS ..... AMP CHAR ..... BEARING ..... TN ORIG ..... PLATFORM ..... FREQUENCY (Hz) .. ELEVATION ANGLE . JRSL .....	<b>LAST REPORT</b> TIMELATE ..... 000:09 RPT DTG ..... 161248Z MAR 95 LAT/LONG ..... 0505S 00318W CSE(T) ..... 000.0 SPD(KT) ..... 0000.0 ALTITUDE ..... AOU TYPE ..... LOB AOU BRG (T)..... ERR ..... RNG ..... SENSOR ..... SOURCE ..... NTDS XREF ..... L11A	
<input type="button" value="PREVIOUS"/> <input type="button" value="NEXT"/> <input type="button" value="EDIT"/> <input type="button" value="EXIT"/>		

#### About the ECM INTERCEPT REPORT Window:

- All fields are view-only.
- Click EXIT to close the window.
- All other buttons are inactive.

#### ECM INTERCEPT REPORT Window Fields:

##### *TRACK NUMBER Box*

The system assigns track numbers when a new track is saved. These fields are

view-only. See *Surface Track Report* for a detailed explanation of each field.

#### *ATTRIBUTES Box*

Many of the fields in the ATTRIBUTES box are the same as those in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

##### **BROAD CLASS**

Broad classification of the emitter.

##### **AMP CHAR**

Amplifying characteristics of the emitter.

##### **BEARING**

Bearing for the track.

##### **TN ORIG**

Track number of the unit that originated the report.

##### **PLATFORM**

Displays platform type.

##### **FREQUENCY (Hz)**

Frequency in Hz.

##### **ELEVATION ANGLE**

Elevation of intercept.

##### **JRSL**

Jammer received signal level.

#### *STATUS Box*

The STATUS box in this window contains fields that are the same as fields in the STATUS box in the NEW SURFACE TRACK REPORT window. See *Surface Track Report* for information about this box.

#### *LAST REPORT Box*

Many of the fields in the LAST REPORT box are the same as the LAST REPORT fields in the NEW SURFACE TRACK REPORT window and are described in *Surface Track Report*. The fields that are unique to this window are described below.

##### **ERR**

AOU bearing error.

##### **RNG**

AOU bearing range.



---

## Search Link Tracks

---

Use the SEARCH LINK TRACKS option to search the track database for a particular Link track or tracks that meet specified search criteria.

1. Select SEARCH LINK TRACKS to open the DATABASE SEARCH window.
  - This window operates the same as the DATABASE SEARCH window.
  - The DATABASE SEARCH window is described in the SEARCH section of the *Software User's Manual, Unified Build (TMS/UCP)* .
2. Tracks which meet the search criteria are highlighted on the display.
3. Click EXIT to close the window.

## Pair/Associate Link Tracks

Use this option to associate tracks or to terminate associations set by your system. This option will not terminate associations received from other PUs.

**To access this window:** TADIL A pull-down menu : PAIR/ASSOCIATE LINK TRACKS option.

This window lists the following information for the selected tracks:

- PU with reporting responsibility.
- Track associations
- AOP relationships
- Controlling relationships
- Identification for this track assigned by other Link channels.

> To associate tracks or break an association:

1. Select a track number from the TN 1 list box.
2. Select a track number from the TN 2 list box.
3. Select ASSOCIATE DATA or TERMINATE PAIRING ASSOCIATION from the select button list.
4. Click OK to accept the changes or CANCEL to discard the process.
  - TN 1 is associated to TN 2, or the association is terminated.
  - A message is sent over the Link indicating the change.

Track association is described in detail in the Track Processing section of the Procedures chapter of the *Software User's Manual, Unified Build (TMS/UCP)*.

## Information Difference

Use this option to compare two reports on the same track (one remote and one local) to see if the information matches.

**To access this window:** TADIL A pull-down menu : INFORMATION DIFFERENCE option.

Information Difference	
Remote Track #	3005 ▼
Local Track #	C1000 ▼
<div> <div> <b>Remote Data</b> </div> <div> <b>Local Data</b> </div> </div>	
CATEGORY	AIR
IDENTITY	FRIEND
PRI AMP	GENERAL
ID AMP	NS
<div> <div>SEND</div> <div>CANCEL</div> </div>	

> To correct track report information:

If remote identification data for a track is different from the local identification data:

1. Determine that information from the local source and the remote source represent the same track.
2. Modify information in the LOCAL DATA box to correct data.
3. Click the SEND button to inform the remote source that the local data is correct and should replace the incorrect data for future reports.
4. Click CANCEL to close the window.

### INFORMATION DIFFERENCE Window Fields:

#### REMOTE TRACK #

Track number assigned by remote source.

#### LOCAL TRACK #

Track number assigned by local source.

*REMOTE DATA Box*

Lists track identification data from the remote source. These fields are view-only.

**CATEGORY**

Track category.

**ID**

Link-11 threat ID.

**PRI AMP**

Click on the list field to display a list of PRI AMP (Primary Amplifier) choices.

**ID AMP**

Further amplification of the identity of the track. Possible entries for this field are determined by the track type.

*LOCAL DATA Box*

Lists track identification data from the local source. These fields can be modified to show accurate information about the track.

## Set Engagement Status

---

Use this option to define the status of weapons engaged on a target.

**To access this window:** TADIL A pull-down menu : SET ENGAGEMENT STATUS option.

ENGAGEMENT STATUS

WEAPON TYPE . . . . . SURFACE TO AIR MISSILE

ENGAGEMENT STATUS . WEAPON ASSIGNED/INVESTIGATING

TN OF FRIENDLY 30 TN OF TARGET 3000

No associated tracks. No associated tracks.

OK CANCEL

This window lists the following information for the selected tracks:

- PU with reporting responsibility.
- Track associations
- AOP relationships
- Controlling relationships
- Identification for this track assigned by other Link channels.

> To set engagement status:

1. Set weapon type.
2. Set engagement status.
3. Select track number of the friendly track.
4. Select track number of target track.
5. Click OK to accept changes or CANCEL to discard.

---

**ENGAGEMENT STATUS Window Fields:****WEAPON TYPE**

Type of weapon.

**ENGAGEMENT STATUS**

Status of weapon engagement.

**TN OF FRIENDLY**

Number of friendly track.

**TN OF TARGET**

Number of target track.


## Xmit on Link

---

Use this option to automatically transmit reports to the Link at regular intervals set by the system. Tracks with a timelate greater than 23:59 will not be transmitted.

- > To transmit reports on the Link:
1. Highlight a track or group of tracks from the tactical display.
    - To search for particular tracks, select XMIT ON LINK with no tracks highlighted to open the SEARCH LINK TRACKS window.
  2. Select XMIT ON LINK from the TADIL A pull-down menu.
  3. The letters LX appear to the lower right of the track on the tactical display. (LR appears for a received track; LN for a non-real time received track.)

Note: Clicking XMIT from the NEW TRACK, EDIT, or SEARCH options will also begin this automatic transmit process.






## Stop Xmit

Use the STOP XMIT option to stop transmitting reports to the Link.

- > To stop transmitting reports on the Link:
  1. Select a track or group of tracks from the tactical display.
    - To search for particular tracks, select XMIT ON LINK with no tracks highlighted. This opens the SEARCH LINK TRACKS window.
  2. Select STOP XMIT from the TADIL A pull-down menu.
  3. The letter L appears to the lower right of the track on the tactical display, as shown in this figure.



## Gridlock

Use the GRIDLOCK option to adjust differences in local and remote position reports for the same track. This ensures that local and remote reports plot the track consistently.

**To access this window:** TADIL A pull-down menu : GRIDLOCK option.

Track Numbers	
Local TN	3005
Remote TN	C0010

Grid Lock Pads	
TN Position Difference	
Delta Latitude	025609S
Delta Longitude	0003825W

### How to Use the GRIDLOCK window:

1. Select a track from the list box in the LOCAL TN field. The position of the selected track appears in the POSITION field.
2. Select a track from the list box in the REMOTE TN field that represents the same track. The position of the selected track appears in the POSITION field.
3. Confirm the two tracks represent the same track.
4. Click SAVE to save the latitude and longitude differences shown in the GRIDLOCK PADS box. Or click EXIT to close window without saving values.
  - All remote reports for a track are adjusted by the values listed in the DELTA LATITUDE and DELTA LONGITUDE fields.

### GRIDLOCK Window Actions:

The following options are available in a pop-up menu in the GRIDLOCK window.

- > **ZERO GRIDPADS**—sets the DELTA LATITUDE and DELTA LONGITUDE values to zero.
  1. Select ZERO GRIDPADS from the pop-up menu.
  2. Click SAVE.
  3. Remote reports for the selected track are positioned without gridlock adjustment.
  
- > **RELOAD GRIDPADS**—resets the DELTA LATITUDE and DELTA LONGITUDE fields to the values that were entered when the GRIDLOCK OPTION was opened.
  1. Select RELOAD GRIDPADS from the pop-up menu.
  2. Click SAVE.
  3. Remote reports for the selected track are adjusted by the values listed in the DELTA LATITUDE and DELTA LONGITUDE fields.

#### GRIDLOCK Window Fields:

##### *TRACK NUMBERS Box*

###### **LOCAL TN**

Number and position of the local track.

###### **REMOTE TN**

Number and position of the remote track.

##### *GRID LOCK PADS Box*

###### **TN POSITION DIFFERENCE**

ON—considers position differences.

Automatically toggles ON when track numbers are selected.

###### **DELTA LATITUDE**

Difference in latitude between the local and remote tracks.

###### **DELTA LONGITUDE**

Difference in longitude between the local and remote tracks.

## GEO Filter

Use this option to define a geographic filter that restricts transmission and receipt of Link tracks. The filter can be defined to transmit and receive only those tracks that are either inside or outside the filter area.

**To access this window:** TADIL A pull-down menu : GEO FILTER option.

**LINK-11 FILTERS**

**FILTER MODE**

☒ OFF  
☐ XMIT  
☐ RCV/XMIT

**SAVE**

NAME	GEO TYPE	CENTER	STATUS	PRIORITY	DISPLAYED
BOX 1	BOX	FIXED POS	INACTIVE	0	NO

**NEW FILTER**   **EDIT**   **DELETE**   **EXIT**

### LINK-11 FILTERS Window Actions:

- > **ACTIVATE FILTER**—Activates the filter.
- > **APPLY**—save changes to the filter mode.
- > **DEACTIVATE FILTER**—Deactivates the filter.
- > **DELETE**—delete a filter.
  1. Highlight a filter in the scroll list.
  2. Click DELETE.
- > **EDIT**—edit a filter.
  1. Highlight one filter in the list.

2. Click EDIT to open the LINK-11 EDIT FILTER window (described in *Add a Filter*).
- > EXIT—close the window.
  - > NEW FILTER—add a new filter. Described in *Add a Filter*.
  - > TOGGLE OVERLAY DISPLAY—Toggles display of filter ON or OFF.

## LINK-11 FILTERS Window Fields

### *FILTER MODE Box*

Choose one diamond knob:

#### **OFF**

Turn the filter off—the filters will have no effect on transmitted or received tracks.

#### **XMIT**

Turn the filter on for transmitted tracks only.

#### **RECV/XMIT**

Turn the filter on for transmitted and received tracks.

Some track types, such as emergency tracks, hostile tracks, assumed enemy tracks, unknown evaluated tracks, Interceptor/Fighter, and tracks with Force Tell ON, continue to be transmitted and received regardless of the filter parameters.

### *FILTERS Box*

#### **NAME**

Name of the filter.

#### **GEO TYPE**

Selected shape.

#### **CENTER**

Selected center.

#### **STATUS**

Indicates active or inactive filter.

#### **PRIORITY**

Selected priority.

**DISPLAYED**

Indicates if filter is displayed.

## Add a Filter

Click NEW FILTER to open the LINK-11 EDIT FILTER window.

LINK-11 EDIT FILTER

NAME:  
PRI:

CAT/THREAT

STANDARD LINK-11/MISC

GEO LOCATION

CENTER ON:

☐ IGNORE  
☐ BOX  
☐ CIRCLE  
☐ SECTOR  
☐ ALLOW INSIDE  
☐ ALLOW OUTSIDE

☐ FIXED POS  
☐ OWNTRACK  
☐ DLRP  
☐ TN#

SAVE CANCEL

- > To edit a filter:
1. Enter a name and priority for the filter.
  2. Click one diamond knob in each box to define filter parameters.
  3. Choose STANDARD or LINK-11/MISC in the CAT/THREAT box.
    - A window opens similar to the Attribute Toggles windows described in the *Software User's Manual, Unified Build (TMS/UCP)*.
    - Toggle ON category and threat criteria for the filter.
  4. Click SAVE to save the filter or CANCEL to discard. Clicking either closes the window.

### LINK-11 EDIT FILTER Window Fields:

**NAME**

Name of the filter.

**PRI**

Priority number for the filter (from 01 to 10, with 01 being the highest priority). When using more than one filter, each filter should be assigned a different priority number.

*CAT/THREAT Box***STANDARD**

Specifies the standard category (Air, Nav, Subsurface, etc.) and threat (Friendly, Hostile, Unknown, etc.) combinations included in the filter.

**LINK-11/MISC**

Specifies the Link-11/Misc categories (Emergency, Hazard, Special, etc.) included in the filter.

*GEO LOCATION Box***IGNORE, BOX, CIRCLE, or SECTOR**

Defines the shape of the geo filter. (Described in following sections.)

**ALLOW INSIDE**

Allows only those tracks within the geo filter area to be transmitted or received.

**ALLOW OUTSIDE**

Allows only those tracks outside of the geo filter area to be transmitted or received.

**FIXED POSITION**

Filter is centered on a fixed position.

**OWNTRACK**

Filter is centered on owntrack.

**DLRP**

Filter is centered on DLRP.

**TN#**

Filter is centered on a specified track.

***IGNORE Diamond Knob***

Accepts track reports for the entire world rather than filtering for a specific geographical area.

## BOX Diamond Knob

Specifies a rectangular filter area for the track reports. An UPPER LEFT and LOWER RIGHT field and an EDIT button appear in the right portion of the GEO LOCATION box.

GEO LOCATION		
<input type="checkbox"/> IGNORE <input type="checkbox"/> BOX <input type="checkbox"/> CIRCLE <input type="checkbox"/> SECTOR	CENTER ON <input type="checkbox"/> FIXED POS <input type="checkbox"/> OWSHIP <input type="checkbox"/> DLRP <input type="checkbox"/> TN#	UPPER LEFT: 000000N 000000E  LOWER RIGHT: 000000N 000000E  <div style="border: 1px solid black; padding: 2px; display: inline-block;">EDIT</div>
<input type="checkbox"/> ALLOW INSIDE <input type="checkbox"/> ALLOW OUTSIDE		

- > To define the filter area:
1. Click EDIT to open the EDIT RECTANGLE window.
  2. Enter lat/long values using one of these methods:
    - Enter lat/long values for the corners of the rectangle in the UPPER LEFT and LOWER RIGHT fields.
    - Draw a filter area directly on the tactical display.
  3. To draw a rectangle:
    - a. Click a point on the tactical display for the upper left corner of the rectangle.
    - b. Move the pointer to the position for the lower right corner of the rectangle, and click the trackball button.
    - c. The lat/long values for the positions automatically fill the UPPER LEFT and LOWER RIGHT fields.
  4. The AREA is automatically calculated regardless of the method used to enter lat/long values.
  5. Specify whether the rectangle's lines are shown as Great Circle (GC) lines or Rhumb lines (RL).
    - Great Circle line—shortest path between two points; may appear curved with some map projections.
    - Rhumb line—straight line on a Mercator projection map.
  6. (Optional) Select EDGE and FILL colors for the displayed filter.



- a. Click the list box and select a color from the list.
  - b. Click OK in the list window to accept the color.
  - c. Toggle the FILL checkbox ON or OFF.
7. (Optional) Select a line type.
8. The NAME is automatically entered. The filter name can only be changed in the LINK-11 EDIT FILTER window.
9. Click OK to accept the settings, or click CANCEL to discard them.

### ***CIRCLE Diamond Knob***

Specifies a circular filter area for the track reports. CENTER and RANGE fields and an EDIT button appear in the right portion of the GEO LOCATION box.

> To define the filter area:

1. Click EDIT to open the EDIT CIRCLE window.
2. Define the center and radius of the circle using one of these methods:

- Enter values in the CENTER and RADIUS fields.
  - Draw the filter area directly on the tactical display.
3. To draw the circle:
    - a. Click a point on the tactical display for the center of the circle.
    - b. Move the pointer outward, creating a circle on the screen, until the circle covers the area for the filter. Click the trackball button.
    - c. The lat/long value of the CENTER and the nautical miles of the RADIUS fill those fields.
    - d. Optional: Use the grab points to adjust the size (radius) of the circle.
    - e. Optional: Move the entire circle to a new location by clicking and holding down the left trackball button on the center point, dragging the circle to a new location, and releasing the trackball button.
  4. The AREA is automatically calculated.
  5. The NAME is automatically entered. The filter name can only be changed in the LINK-11 EDIT FILTER window.
  6. (Optional) Select EDGE and FILL colors for the displayed filter.
    - a. Click the list box and select a color from the list.
    - b. Click OK in the list window to accept the color.
    - c. Toggle the FILL checkbox ON or OFF.
  7. (Optional) Select a line type.
  8. Click OK to accept the settings, or click CANCEL to discard them.

**EDIT CIRCLE**


NAME . . . . . CIRCLE FILTER  
AREA . . . . . 0.0 SQ NM  
CENTER . . . . . 000000N 000000E  
RADIUS . . . . . 0000.0

**COLORS**

☐ EDGE COLOR  
☐ FILL COLOR  
☐ FILL TOGGLE

**LINE TYPE**

☐ DASHED  
☐ SOLID

 **- OK -** **CANCEL**

## SECTOR Diamond Knob

Specifies a sector filter area for the track reports. CENTER, BRG 1, BRG 2, two RANGE fields and an EDIT button appear in the right portion of the GEO LOCATION box.

GEO LOCATION		
<input type="checkbox"/> IGNORE <input type="checkbox"/> BOX <input type="checkbox"/> CIRCLE <input type="checkbox"/> SECTOR	CENTER ON <input type="checkbox"/> FIXED POS <input type="checkbox"/> OWSHIP <input type="checkbox"/> DLRP <input type="checkbox"/> TN#	CENTER:0210N 16198E BRG 1: 000000 BRG 2: 000000 RANGE: 2 NM RANGE: 4 NM
<input type="checkbox"/> ALLOW INSIDE <input type="checkbox"/> ALLOW OUTSIDE	10 <input type="button" value="v"/>	<input type="button" value="EDIT"/>

- > To define the filter area:
1. Click EDIT to open the EDIT SECTOR window.
  2. Define the center, bearings, and inner and outer range of the sector using one of these methods:
    - Enter values in the appropriate fields.
    - Draw the filter area directly on the tactical display.
  3. To draw the sector:
    - a. Click a point on the tactical display for the center of the sector.
    - b. Move the pointer outward, creating a sector on the screen, until the sector covers the area for the filter. Click the trackball button.
    - c. The lat/long value of the center, and the bearing and range values fill those fields.
    - d. Optional: Use the grab points to adjust the size of the sector.
    - e. Optional: Move the entire sector to a new location by clicking and holding down the left trackball button on the center point, dragging the sector to a new location, and releasing the trackball button.
  4. The AREA is automatically calculated.
  5. The NAME is automatically entered. The filter name can only be changed in the LINK-11 EDIT FILTER window.

6. (Optional) Select EDGE color for displayed filter.
  - a. Click list box and select a color from the list.
  - b. Click OK in the list window to accept the color.
7. Specify whether the sector's lines are shown as Great Circle (GC) lines or Rhumbines (RL).
  - Great Circle line—shortest path between two points; may appear curved with some map projections.
  - Rhumbline—straight line on a Mercator projection map.
8. (Optional) Select a line type.
9. Click OK to accept the settings, or click CANCEL to discard them.

**EDIT SECTOR**

NAME . . . . . SECTOR FILTER  
 AREA . . . . . 0.0 SQ NM  
 CENTER . . . . . 000000N 000000E  
 BRG 1 . . . . . 0000.0  
 BRG 2 . . . . . 0000.0  
 INNER RNG . . 0000.0  
 OUTER RNG . . 0000.0

GC/RL  
☒ GC  
☐ RL

COLOR  
☐ EDGE COLOR

LINE TYPE  
☒ DASHED  
☐ SOLID

- OK - CANCEL


## Edit a Filter

To edit the parameters for a filter, highlight the filter in the list and click EDIT to open the LINK-11 EDIT FILTER window (described in *Add a Filter*).

## Update Request

Use this option to request the most recent track reports from a particular PU.

Select UPDATE REQUEST from the TADIL A pull-down menu to open the UPDATE REQUEST window.



- > To request track report updates:
1. Click the list box to display a list of all available PUs.
  2. Choose one PU from the list.
  3. Click OK to send the request, or CANCEL to close the window without sending the request.

## Receive Quality

Use this option to view the status of the transmission quality for all PUs.

**To access this window:** TADIL A pull-down menu : RECEIVE QUALITY option.

The screenshot shows a window titled "Link Monitor". It contains a "STATUS" section with the following information:

- STATUS:RECEIVE.ONLY
- #PTRs: 124
- DELTA LAT: 0031S
- #PTTs: 54
- DELTA LNG: 00229E

Below the status section is a "RECEPTION QUALITY" section with a sub-header "Source of RQ Report". It contains a table with the following data:

Ref PU	10	21	30	40	50	76
10	N/A	7		7	3	7
21	7	N/A		7	3	7
30	0	0	N/A	0	0	0
40	7	7		N/A	3	7
50	7	7		7	N/A	7
76	4	4		4	2	N/A
NCT	5	5	0	5	3	5
CNTR-RCV/XMIT	134	133	0	133	134	134
GMT	15:34:37	15:34:38	00:00:00	15:34:38	15:34:40	15:34:42

Below the table, it says "Received Message Error Rate: 0%". At the bottom of the window are three buttons: CLEAR, CANCEL, and HELP.

Note: TADIL-B options are described in Appendix A.

### About the LINK MONITOR window:

- This window is view-only and cannot be edited.
- The information automatically updates every five seconds.

### LINK MONITOR Window Actions:

- > Click CLEAR to reset values to zero.
- > Click CANCEL to close the window.

**LINK MONITOR Window Fields:***STATUS Box***STATUS**

Displays the current receive/transmit status of the system (set from the LINK STATUS option). Values include OFF LINE, RECEIVE ONLY, RECEIVE/TRANSMIT, or FAST TRANSMIT.

**#PTRs**

Displays the number of Prepare To Receive (PTR) messages received since CLEAR was last clicked. If this number continues to increase, the system is receiving properly.

**#PTTs**

Displays the number of Prepare To Transmit (PTT) messages sent since CLEAR was last clicked. If this number continues to increase, the system is transmitting properly.

**DELTA LAT AND DELTA LNG**

Current gridlock pad position.

*RECEPTION QUALITY Box*

The Reception Quality box displays a matrix of PUs and the status of transmitted and received quality values for all PUs.

- Each column represents a receiving PU.
- Each row represents a transmitting PU.
- The point where each row and column intersect, displays a number indicating the receive quality between the two PUs.
  - Reception quality is displayed as a number from 0 to 7, with 7 representing the best quality and 0 representing a PU that has gone inactive.
  - If a column is blank, that PU is not reporting receive quality.

For example, in the figure above:

- PU30 is not reporting receive quality—the column is blank.
- The receive quality from PU76 to all other PUs is 4, indicating PU76 has a possible transmission problem.
- The receive quality for PU50 is 3, indicating that PU50 has a possible reception problem.
- The receive quality between PU76 and PU50 is 2, resulting from their respective transmission and reception problems.

**NCT (Net Cycle Time)**

Displays the time (in seconds) between PTT messages reported by each PU.

**COUNTER**

Displays the most current serial number transmitted by the PU.

**GMT (Greenwich Mean Time)**

Displays the current system time being reported by each PU.

**RECEIVED MESSAGE ERROR RATE**

Percentage of messages received by Owntrack containing errors. This figure is based on all messages received from all PUs.



## Send Aircraft Control Order

Use this option to send an order to transfer control of an aircraft, or to indicate the aircraft is to return to base.

**To access this window:** TADIL A pull-down menu : SEND AIRCRAFT CONTROL ORDER option.

Send Order

ORDER ..... TRANSFER CONTROL

TN OF ADDRESSEE .....76 ▼

TN-1 (TN OF AIRCRAFT) .....4500 ▼

TN-2 (TN OF DESTINATION) ....56 ▼

OK CANCEL

- > To send an Aircraft Control Order:
1. Select order to send.
  2. Click down arrow and select track numbers of addressee, aircraft, and destination.
  3. Click OK to send, or CANCEL to discard.

### SEND ORDER Window Fields:

**ORDER**

Either TRANSFER CONTROL or RETURN TO BASE.

**TN OF ADDRESSEE**

Track with control of aircraft.

**TN1**

Track number of aircraft.

**TN2**

Unit requested to assume control, or home base of aircraft.

## Command Messages

Use the COMMAND MESSAGES option to view a scrolling list of command messages transmitted or received by the system and to send or view command messages.

**To access this window:** TADIL A pull-down menu : COMMAND MESSAGES option.

Link11-A: Command Messages

Commands Transmitted

Number of Messages: 1

ACTION	DTG	RESPONSE
CEASE FIRE	161248Z MAR 95	WILCO

Commands Received

Number of Messages: 1

ACTION	DTG	RESPONSE
CEASE FIRE	161248Z MAR 95	WILCO

SEND VIEW DELETE EXIT

> About the COMMAND MESSAGES window:

- All implementations will show Commands Received list.
- If the system implementation supports transmitting command messages, the window will contain two lists: Commands Transmitted and Commands Received.

- Click the small box on the horizontal line between the two sections and drag up or down to adjust the size of each section.

### COMMAND MESSAGES Window Actions;

- > DELETE—a command message.
  1. Highlight one or more messages.
  2. Click DELETE.
- > EXIT—the window.
- > SEND—a command message (described in *Send Command Message*).
- > VIEW—a command message (described in *View Command Message*).

### COMMAND MESSAGES Window Fields

**NUMBER OF MESSAGES**

Number of messages in the scroll list.

**ACTION**

Type of command message.

**DTG**

Date and time message was transmitted or received.

**RESPONSE**

Response to message.

WILCO (Will Comply)

CANTCO (Can't Comply)

CANTPRO (Can't Process)

NONE REQUIRED

## Received Command Messages

When a command message is received, an alert is generated on the Link Supervisor machine.

- The Link Supervisor responds to the alert by clicking WILCO (will comply) or a CANTCO (can't comply).
- The command message is automatically entered into the Commands

Received message log.

## Send Command Message

Command messages request an action be taken by the Addressee. Click SEND in the COMMAND MESSAGES window to open the SEND COMMAND MESSAGE window.

The screenshot shows a window titled "Send Command Message". It contains the following fields and controls:

- COMMAND ORDER**: A dropdown menu with "SALVO/CLEAR AIRCRAFT" selected.
- WEAPON TYPE**: A dropdown menu with "ANY/ALL WEAPON SYSTEMS" selected.
- ALERT CONDITION**: A dropdown menu with "NS" selected.
- TN OF ADDRESSEE**: A list box with "76" selected.
- TN-1 (TN OF WEAPON SYSTEM)**: A list box with ".4500" selected.
- TN-2 (TN OF TARGET)**: A list box with "5670" selected.
- Buttons**: "OK" and "CANCEL" buttons at the bottom.

- > To send a command message:
1. Select a command order, weapon type, and alert condition from the select-button lists.
  2. Select track number of addressee, track number of weapon system, and track number of target from the list boxes.
  3. Click OK to send the command message or CANCEL to discard.

### SEND COMMAND MESSAGE Window Fields:

#### **COMMAND ORDER**

Type of command message.

#### **WEAPON TYPE**

Type of weapon.

#### **ALERT CONDITION**

Importance of command message.

#### **TN OF ADDRESSEE**

Track number to receive the order. Can be sent to all tracks.

#### **TN-1**


Track number that has the selected weapon system.

**TN-2**

Track number of target.

## View Command Message

The COMMAND MESSAGE window displays additional information about the selected message.



- > To view a command message:
  1. Highlight one or more messages in the scroll list.
  2. Click VIEW to open the COMMAND MESSAGE window.

### COMMAND MESSAGE Window Actions


- > DELETE—the displayed message.
- > EXIT—the COMMAND MESSAGE window and return to the COMMAND MESSAGES window.
- > NEXT—view next message (when more than one message is selected).
- > PREVIOUS—view previous message (when more than one message is selected).

## Monitor Database Size

---

Use this option to display the number of Link tracks in the system.

**To access this window:** TADIL A pull-down menu : MONITOR DATABASE SIZE option.



This window is view-only.

- A slider in the first column displays the number of Link tracks in the system relative to the total number of Link tracks allowed in the database.
- A rotating symbol in the second column indicates updates are being received on the Link-11 channel.
- To close the window, click the window menu box in the upper left corner and choose CLOSE from the list.

## Read Plain Text

Use the READ PLAIN TEXT option to:

- view plain text messages that have been received
- create and send a new message

**To access this window:** TADIL A pull-down menu : READ PLAIN TEXT option.

DTG	SERIAL	PU	SECURITY	ROGER	STATUS
210007.DEC.94	1	13	UNCLASSIFIED	NOT REQ'D	RECEIVED

REVIEW PRINT DELETE EXIT

### RECEIVED PLAIN TEXT MESSAGE SELECTION Window Actions:

- > **AUTO REFRESH ON/OFF**—When toggled ON, a dot appears next to the option and the list of received messages is automatically updated.
- > **DELETE**—delete a message.
  1. Highlight one or more messages in the list.
  2. Click DELETE.
- > **EXIT**—close the window.
- > **NEW MESSAGE**—Create a new plain text message. (Described in *Create New Plain Text Message*.)
- > **PRINT**—selected message.

- > **REVIEW**—View message. (Described in *View Plain Text Messages*.)
- > **SET AUTO REFRESH TIME**—Set the interval, in minutes or seconds, at which the list automatically updates.

#### RECEIVED PLAIN TEXT MESSAGE SELECTION Window Fields:

**DTG**

Time message was received.

**SERIAL**

Message number generated by the system to identify the message.

**PU**

PU number that sent the message.

**SECURITY**

Security level of the message.

**ROGER**

Indicates whether a roger is required for the message.

**STATUS**

Received and rogered status. If a roger is not required, this column displays RECEIVED. If a roger is required, this column displays whether the message was rogered or not.

## View Plain Text Messages

To view a plain text message, select one or more messages in the RECEIVED PLAIN TEXT MESSAGE SELECTION window, and click REVIEW to open the PLAIN TEXT MESSAGE window.



Plain Text Message

DTG: 210007Z.DEC.94    SERIAL# 36    PU 10    SECURITY UNCLASSIFIED  
ROGER NOT REQ'D    STATUS RECEIVED

THIS IS A TEST MESSAGE.

PREV   NEXT   DUPLICATE   PRINT   REQUEST RE-XMIT   ROGER   REPLY   DELETE   EXIT

The PLAIN TEXT MESSAGE window displays identification information and text for the selected message.

#### PLAIN TEXT MESSAGE Window Actions:

- > DELETE—the message.
- > DUPLICATE—create a duplicate copy of the message.
  1. Click DUPLICATE to open new PLAIN TEXT MESSAGE window containing the duplicate message.
  2. Make changes to the message, if needed.
  3. Click SEND/RESEND to transmit the message, or click SAVE to save the message without transmitting.
- > EXIT—close the window and return to the RECEIVED PLAIN TEXT MESSAGE SELECTION window.
- > NEXT—view next message (if more than one message was selected).
- > PREVIOUS—view previous message (if more than one message was selected).

- > PRINT—the message.
- > REPLY—send a reply to the message.
  1. Click REPLY to open new PLAIN TEXT MESSAGE window.
  2. Enter a reply in the text field.
  3. Click SEND/RESEND to transmit, or click SAVE to save the message without transmitting.
- > REQUEST RE-XMIT—request a retransmission of the message (if the message appears garbled or is missing data).
- > ROGER—send a roger, if required.

#### PLAIN TEXT MESSAGE Window Fields:

**DTG**

Date-time group of the message.

**ROGER**

Indicates whether a roger is required.

**SERIAL**

Message number assigned by the system.

**PU**

Number of the participating unit that transmitted the message.

**SECURITY**

Classification of the message.

**STATUS**

Status of the message.

## Create New Plain Text Message

To create a new plain text message, open the PLAIN TEXT MESSAGE window one of two ways:

- Select NEW MESSAGE from the RECEIVED PLAIN TEXT MESSAGE SELECTION window pop-up menu.
- Click REPLY when viewing a message.

Plain Text Message

DTG SERIAL# 36 PU 10 SECURITY UNCLASSIFIED

ROGER NOT REQ'D STATUS NOT BEING SENT

SEND/RESEND SAVE EXIT

- > To create a new plain test message:
1. Enter text in the scroll box.
  2. Click the down arrow next to the PU field and select the PU to receive the message.
  3. Click the SECURITY select button and choose a classification for the message.
  4. Click the ROGER select button and specify if a roger is required.
  5. Click SEND/RESEND to send the message or SAVE to save the message without transmitting.
  6. Click EXIT to close the window.

#### PLAIN TEXT MESSAGE Window Fields:

**DTG**

Date-time group of the message. This value is automatically entered when SEND/RESEND is clicked.

**ROGER**

Indicates whether a roger is required for the message.

**SERIAL**

Message number assigned by the system.

**PU**

Number of the participating unit transmitting the message.

**SECURITY**

Classification of the message.


**STATUS**

Status of the message.

## Create Plain Text Message

Use this option to create and transmit plain text messages.

Select CREATE PLAIN TEXT MESSAGE from the TADIL A pull-down menu to open the TRANSMITTED PLAIN TEXT MESSAGE SELECTION window.



DTG	SERIAL	PU	SECURITY	ROGER	STATUS
081524Z.DEC.94	01	0	UNCLASSIFIED	REQUIRED	SENDING
151206Z.DEC.94	T02	10	UNCLASSIFIED	NOT REQ'D	NOT BEING SENT
151218Z.DEC.94	05	50	UNCLASSIFIED	NOT REQ'D	SENDING
151219Z.DEC.94	T06	10	UNCLASSIFIED	NOT REQ'D	NOT BEING SENT
151220Z.DEC.94	07	10	UNCLASSIFIED	NOT REQ'D	SENDING

REVIEW   NEW MESSAGE   PRINT   DELETE   EXIT

The TRANSMITTED PLAIN TEXT MESSAGE SELECTION window displays a list of plain text messages that have been saved or transmitted.

### TRANSMITTED PLAIN TEXT MESSAGE SELECTION Window Actions:

- > **AUTO REFRESH ON/OFF**—When toggled ON, a dot appears next to the option and the list of received messages is automatically updated.
- > **DELETE**—delete a message.
  1. Highlight one or more messages in the list.
  2. Click DELETE.
- > **EXIT**—close the window.
- > **NEW MESSAGE**—create a new message. (Described in *Create a Plain Text Message*.)
- > **PRINT**—selected message.

- > **REVIEW**—view message. (Described in *View Transmitted Plain Text Message*.)
- > **SET AUTO REFRESH TIME**—Set the interval, in minutes or seconds, at which the list automatically updates.

#### **TRANSMITTED PLAIN TEXT MESSAGE SELECTION Window Fields:**

**DTG**

Time message was transmitted.

**SERIAL**

Message number assigned by the system. If a T precedes the number, the message has not been sent.

**PU**

Recipient PU number.

**SECURITY**

Classification of the message.

**ROGER**


Indicates whether a roger is required.

**STATUS**

Sending status of the message and the roger-received status.

## **View Transmitted Plain Text Messages**

To view a transmitted message, highlight one or more messages in the TRANSMITTED PLAIN TEXT MESSAGE SELECTION window and click REVIEW to open the PLAIN TEXT MESSAGE window.



#### PLAIN TEXT MESSAGE Window Actions:

- > DELETE—delete the message.
- > DUPLICATE—create a duplicate copy of the message.
  1. Click DUPLICATE to open a new PLAIN TEXT MESSAGE window containing the duplicate message.
  2. Make changes to the message, if needed.
  3. Click SEND/RESEND to transmit the message, or click SAVE to save the message without transmitting.
- > EDIT—edit a message.
  1. Click EDIT to open a new PLAIN TEXT MESSAGE window containing the message text.
  2. Make changes to the message.
  3. Click SEND/RESEND to transmit the message, or click SAVE to save it without transmitting.
- > EXIT—close the window and return to the TRANSMITTED PLAIN TEXT MESSAGE SELECTION window.

- > NEXT—view next message (if more than one message was selected).
- > PREVIOUS—view previous message ( if more than one message was selected).
- > PRINT—the message.
- > SEND/RESEND—send the message.

#### PLAIN TEXT MESSAGE Window Fields:

**DTG**

Date-time group of the message. This value is automatically entered when SEND/RESEND is clicked.

**ROGER**

Indicates whether a roger is required.

**SERIAL**

Message number assigned by the system.

**PU**

Number of the participating unit transmitting the message.

**SECURITY**

Classification of the message.

**STATUS**

Status of the message.

## Create New Plain Text Message

To create a new message or edit an existing message, open the PLAIN TEXT MESSAGE window one of two ways:

- Click NEW MESSAGE from the TRANSMITTED PLAIN TEXT MESSAGE SELECTION window.
- Click EDIT when viewing a transmitted message.



Plain Text Message

DTG SERIAL# 36 PU 10 SECURITY UNCLASSIFIED

ROGER NOT REQ'D STATUS NOT BEING SENT

SEND/RESEND SAVE EXIT

- > To create a new plain text message:
1. Enter text in the scroll box.
  2. Click the down arrow next to the PU field and select the PU to receive the message.
  3. Click the SECURITY select button and choose a classification for the message.
  4. Click the ROGER select button and specify whether a roger is required.
  5. Click SEND/RESEND to send the message or SAVE to save the message without transmitting.
  6. Click EXIT to close the window.

#### PLAIN TEXT MESSAGE Window Fields:

**DTG**

Date-time group of the message. This value is automatically entered when SEND/RESEND is clicked.

**ROGER**

Indicates whether a roger is required.

**SERIAL**

Message number assigned by the system.

**PU**

Number of the participating unit to receive the message.

**SECURITY**

Classification of the message.


**STATUS**

Status of the message.

## ASW Summary

Use the ASW SUMMARY option to view a list of received ASW summary reports and display selected information contained in the reports.

**To access this window:** TADIL A pull-down menu : ASW SUMMARY option.



- > To view ASW summary reports:
1. Highlight one or more tracks in the list.
  2. Toggle checkboxes ON for information to be displayed.
  3. Click REFRESH to clear the display and show the most recent summary list.
  4. Click SHOW to display the track and its information.
  5. Click HIDE to remove the track from display.
  6. Click EXIT to close the window.

## XMIT DLRP

---

The DLRP position is transmitted periodically if XMIT DLRP is checked in the LINK CONFIGURATION window. Use XMIT DLRP to immediately transmit the position of the DLRP without waiting for the next regular transmission. The periodic transmission interval is not changed.

> To transmit DLRP position:

1. Choose XMIT DLRP from the TADIL A menu.
2. If more than one Link channel is active, a window will open to choose which DLRP to transmit. Select one and click OK.
3. Click TRANSMIT in the TRANSMIT DLRP window to immediately transmit the DLRP position, or click CANCEL to discard the process.


## Link Supervisor

Use the LINK SUPERVISOR option to view or change the Link Supervisor setting. Only one machine can be designated the Link Supervisor. This is the only machine that can be used to:

- receive alerts
- define track block assignments
- define weapon status
- define Link configuration

The Link Supervisor can also be set from the EDIT LNK11 window.

**To access this window:** TADIL A pull-down menu : LINK SUPERVISOR option.



Link Supervisor	
SELECT LINK SUPERVISOR MACHINE	
SUPERVISOR MACHINE	mach1 ▼
SUPERVISOR DISPLAY	Remote 1 ▼
OK Cancel Help	

### How to Use the LINK SUPERVISOR Window:

1. In the SUPERVISOR MACHINE field, click the down arrow and choose a machine from the list.
2. In the SUPERVISOR DISPLAY field, click the down arrow and choose a monitor from the list.
3. Click OK to save the changes, or CANCEL to discard. Clicking either closes the window.

## Track Block Assignment

The TRACK BLOCK ASSIGNMENT option is available only from the Link Supervisor machine. To avoid duplicate track numbers, use this option to select a block of track numbers for a specific PU to assign to tracks.

**To access this window:** TADIL A pull-down menu : TRACK BLOCK ASSIGNMENT option.

Link Track Block Assignment

OWN STATION: 30

Track Block

STARTING TN: 3000  
ENDING TN: 3577

Track Quality Block

TQ LIMIT ..... 7  
DEFAULT TQ. .... 7  
REAL TIME THRESHOLD (MIN/SEC) 00:00

SAVE QUIT

- > To select a Link track block:
  1. Enter data in each field to define the track block.
  2. Click SAVE to accept changes or QUIT to discard. Clicking either closes the window.

### LINK TRACK BLOCK ASSIGNMENT Window Fields:

#### OWNSTATION PU

Enter your (Ownstation) PU.

#### STARTING TN

First track number assigned by the system. Each additional track created is assigned a number increased by one.

If other PUs have selected the same range of numbers, track numbers for these PUs will be assigned sequentially from this pool of numbers.

For example:

- PU30 and PU45 both select the range 3000 to 3577.

- PU30 creates a track-assigned number 3000.
- PU45 creates the next track, and it is assigned 3001.
- PU30 creates the third track, and it is assigned 3002.

**ENDING TN**

Ending track number in the track block assignment.

- The range of values is 200-7777.
- The recommended range is a difference of no more than 600.

**TQ LIMIT**

Maximum track quality value.

**DEFAULT TQ**

Track quality value assigned by system if a value is not specified by the user in the track report window.

**REAL TIME THRESHOLD (MIN/SEC)**

Value used to determine if track is a real time track. A track older than the set value is a non-realtime track.

## Weapon Status

The WEAPON STATUS option is available only from the Link Supervisor machine. Use this option to enter the inventory and availability of medium and long range weapons. This information is included with any data transmitted about Owntrack.

**To access this window:** TADIL A pull-down menu : WEAPON STATUS option.

LINK11-A: Weapon Status

Own Station PU: 30

WEAPONS STATUS

MEDIUM RANGE SURFACE TO SURFACE MISSILE

Cold Inventory ... 0

Hot Inventory .... 0

Availability ..... Out of Action

LONG RANGE SURFACE TO SURFACE MISSILE

Cold Inventory ... 0

Hot Inventory .... 0

Availability ..... Out of Action

SAVE QUIT

- > To set weapon status:
  1. Enter data for medium and long range weapons:
    - a. Enter data in COLD INVENTORY, and HOT INVENTORY.
    - b. Click on the AVAILABILITY field and choose AVAILABLE or OUT OF ACTION.
  2. Click SAVE to accept changes or QUIT to discard. Clicking either closes the window.

### WEAPON STATUS Window Fields:

#### *MEDIUM RANGE SURFACE TO SURFACE MISSILE Box*

##### **COLD INVENTORY**

Number of weapons aboard the ship that are not ready to operate.



**HOT INVENTORY**

Number of weapons aboard the ship that are ready to operate.

**AVAILABILITY**

Availability status of weapons.

*LONG RANGE SURFACE TO SURFACE MISSILE Box***COLD INVENTORY**

Number of weapons aboard the ship not ready to operate.

**HOT INVENTORY**

Number of weapons aboard the ship ready to operate.


**AVAILABILITY**

Availability status of weapons.

## Link Status

The LINK STATUS option is available only from the Link Supervisor machine. Use this option to set the Link transmit/receive state.

**To access this window:** TADIL A pull-down menu : LINK STATUS option.



Note: TADIL-B options are described in Appendix A.

- > To configure the Link:
1. Select one diamond knob in LINK STATE box.
  2. Click AMP REQUIRED to toggle ON or OFF.
  3. Set TADIL A Guard List (described in *TADIL A Guard List Box*).
  4. Click SAVE to accept changes, or EXIT to discard. Clicking either closes the window.

### LINK CONFIGURATION Window Fields:

#### *LINK STATE Box*

##### **OFF LINE**

Turn off Link transmit and receive capability.

##### **RECEIVE ONLY**

Turn on Link receive capability and turn off transmit capability.

##### **RECEIVE/TRANSMIT**

Turn on Link transmit and receive capability.

**FAST TRANSMIT**

Turn on Link transmit and receive capability to transmit as soon as possible rather than regular intervals.

*LINK CONTROL Box***AMP REQUIRED**

ON—accept only tracks that contain amplification data.

- The first received report for a track will be accepted if it contains amplification data.
- Subsequent received reports for these tracks will be accepted with or without amplification data.

OFF—accept all tracks.

**XMIT DLRP**

Transmit DLRP position.

*TADIL A GUARD LIST Box*

The system accepts messages only from PUs designated in the Guard List. The Guard List can include all PUs, designated as “ALL”, or only specific PUs.

To add a PU to the Guard List:

1. Click ADD.
2. Type PU numbers in the list or click the down arrow in the ADD window to display a list of PUs and select one PU from the list.
3. Click OK to add PU to the list, or click CANCEL to discard.

To delete a PU from the Guard List:

1. Highlight one PU in the list.
2. Click DELETE.
3. Click SAVE to save changes, or QUIT to discard.

# Programmed Operational Functional Appraisal (POFA)

POFA is a hardware diagnostic tool that tests the NTDS data path by sending a known pattern of words through the Data Terminal Set (DTS) communications circuit and checking the pattern for errors.

- In the single-station mode, the test data is sent through the DTS and back to Ownstation.
- In multi-station mode, the test data is transmitted to and received from other participating stations.

Use the COMMUNICATIONS option in the Comms pull-down menu to specify settings to add, configure, start, and stop the various communications interfaces. For a thorough discussion of this option, refer to the Communications section of the Comms chapter in the *Software User's Manual, Unified Build (TMS/UCP)*.

**To access this window:** COMMS pull-down menu : COMMUNICATIONS option.

COMMUNICATIONS							
NAME	XRF	INT	INTERFACE	MACHINE	DEVICE	STARTUP	STATUS
2WAYLINK11	2WL	EXT	LINK11ACT	MACH12	NTDSO	MANUAL	OFF
GFCPLAN	GFP	EXT	GFCPLAN	MACH12	LAN	MANUAL	ON
GFCP-TERM		INT	VT100TERM	MACH12	TTYA	MANUAL	OFF
FCS	FCS	EXT	FCS	MACH18	NTDSO	MANUAL	OFF
SERIAL	SRL	INT	SERIAL	MACH12	TTYA	MANUAL	OFF
OTCIXS	OTC	INT	OTCIXS	MACH12	TTYA	MANUAL	OFF
POFA	PFA	INT	POFA	MACH12	NTDSO	MANUAL	ON

ADD
EDIT
DELETE
EXIT

The COMMUNICATIONS window displays a list of communications channels available in the system.

- A POFA channel and interface must be added to this list and turned on after the POFA segment is loaded.
- The COMMUNICATIONS window may contain a maximum of 32 channels. An existing channel may need to be deleted before adding the POFA channel.

- Detailed instructions for adding a new channel can be found in the Comms chapter of the *Software User's Manual, Unified Build (TMS/UCP)*.

## Edit POFA Window

To view and edit POFA channel settings, highlight the POFA channel in the COMMUNICATIONS window and click EDIT to open the EDIT POFA window.

The screenshot shows the 'EDIT POFA' window with the following settings:

- CHANNEL**
  - NAME ..... POFA-A
  - INTERFACE ... POFA
  - DEVICE ..... NTDS0
  - MACHINE ..... MACH1
- SUPERVISOR**
  - DEVICE ..... NTDS0
  - MACHINE ..... MACH1
- NTDS TYPE**
  - ☒ TYPE A (SLOW)
  - ☐ TYPE B (FAST)
  - ☐ TYPE C (ANEW)
- EXTRA BIT PATTERN**
  - ☒ NONE
  - ☐ TSC/P3

At the bottom are buttons for '- OK -' and 'CANCEL'.

> To edit a POFA channel:

1. In the CHANNEL box:
  - Click the DEVICE select button and choose a device name from the list.
  - Click the MACHINE select button and choose a machine from

the list.

3. In the NTDS TYPE box, choose one diamond knob for the NTDS type.
3. Choose one diamond knob to indicate if the EXTRA BIT PATTERN is to be used.
5. Click OK to accept the new settings or CANCEL to discard.

#### EDIT POFA Window Fields:

##### *CHANNEL Box*

**NAME**

Name of the channel. This field cannot be edited.

**INTERFACE**

Communications interface for the channel. This field cannot be edited.

**DEVICE**

Name of NTDS device.

**MACHINE**

Name of the machine used to transmit or receive message on this channel.

##### *NTDS TYPE Box*

Designates type of NTDS: TYPE A (FAST), TYPE B (SLOW), or TYPE C (ANEW).

##### *EXTRA BIT PATTERN Box*


Designates if an extra bit test pattern is to be used within the 130 word status block when in multi-station mode.

## POFA Single- or Multi- Station Summary Window

The POFA Single- or Multi- Station Summary window monitors status and data flow on the POFA interface.

- More than one channel (each using a different interface) may be assigned to a device. Only one channel may be ON for each device.
- This window contains information only after it is configured. (Described in *Configure*.)
- All fields in this window are view-only.

Highlight the POFA interface in the COMMUNICATIONS window and choose START from the pop-up menu to open the POFA SUMMARY window.



This window provides a summary of POFA data and also provides access to additional information. The window title will be POFA SINGLE-STATION SUMMARY or POFA MULTI-STATION SUMMARY depending on the mode set in the CONFIGURATION window. (Described in *Configure*.) The window remains open until the channel is stopped.

### POFA SUMMARY Window Actions:

- > BITS—view parity status and bit information for reception from a given station. (Described in *Bit Display*.)
- > CLEAR DATA (pop-up option)—Set values to zero.
- > CONFIG—the POFA and RECEIVE modes. (Described in *Configure*.)

- > INTERRUPTS—view interrupt codes and error counts. (Described in *Interrupt Codes*.)
- > MULTI-MATRIX—view error rates between reporting stations. (Described in *Multi-Station Mode*.)
- > SIMULATE DTS RESET (pop-up option)—toggles DTS state from INACTIVE to ACTIVE.
- > RESTART—clear all previously collected data from the POFA SUMMARY window and reset all parameters to default values. New summary data will immediately begin to accumulate.

#### POFA SUMMARY Window Fields:

##### **OWNSTATION**

The number which identifies Ownstation. The default number (1) appears the first time POFA is turned on. Subsequently, this field displays the last number assigned to Ownstation.

##### **AIR TIME**

Total time the channel has transmitted.

##### **# PTTs**

Total number of *Prepare to Transmit* messages from the Data Terminal Set (DTS) when data transmission is expected.

##### **# PTRs**

Total number of *Prepare to Receive* messages from the DTS when data is about to be received.

##### **RECEIVE MODE**

The receive mode set in the POFA CONFIGURATION window—OFFLINE, RECV ONLY, or RECV/XMIT.

##### **# WRDS XMITTED**

Total number of words transmitted.

##### **# WRDS RECEIVED**

Total number of words received.

##### **# WRDS IN ERROR**

Total number of words which contain errors in the established pattern.

##### **ERROR RATE**

The ratio of words in error to total words received.




**DTS STATE**

Data Terminal Set (DTS) status is shown as ACTIVE, INACTIVE, or TIMEOUT.

## Configure

The POFA MODE and RECEIVE MODE must be set in the POFA CONFIGURATION window before data will be available in the SUMMARY window.

Click CONFIGURE in the SUMMARY window to open the POFA CONFIGURATION window.



The screenshot shows a window titled "POFA CONFIGURATION". Inside, there is a label "OWN STATION:" followed by the value "30". Below this, there are two sections. The first section is labeled "POFA MODE" and contains two radio button options: "SINGLE STATION" (which is selected) and "MULTI-STATION". The second section is labeled "RECEIVE MODE" and contains three radio button options: "OFFLINE" (which is selected), "RECV ONLY", and "RECV/XMIT". At the bottom of the window, there are two buttons: "APPLY" and "CANCEL".

> To configure POFA:

1. Enter Ownstation identification number.
  - The default identification number for Ownstation is 1.
  - The number is set by the Area Link Coordinator.
2. Set POFA mode. POFA mode can *only* be changed when the RECEIVE mode is OFFLINE. If necessary:
  - a. Change RECEIVE mode to OFFLINE.

- b. Click APPLY (window will close).
  - c. Re-open window and set POFA mode.
3. Set RECEIVE MODE.
4. Click APPLY to accept the changes or CANCEL to discard.

#### POFA CONFIGURATION Window Fields:

##### **OWNSTATION**

Ownstation identification number.

##### **POFA MODE**

SINGLE STATION sends test data through the DTS and back to Ownstation.

MULTI-STATION transmits to and receives test data from other participating units.

##### **RECEIVE MODE**

OFFLINE is the default value for the RECEIVE MODE.

In single-station mode, RECV/XMIT must be used to both transmit and receive the test data.

In multi-station mode, use RECV ONLY to only receive test data. Use RECV/XMIT to both receive and transmit test data.

## Bit Display

Use this button to view parity status and bit information for reception from a given station.

Click BIT DISPLAY from the POFA SUMMARY window to open the POFA BIT DISPLAY window.

POFA SINGLE-STATION BIT DISPLAY			
OWN STATION NO:30			
REPORTED STATION NO: 30			
PARITY STATUS			
PARITY	# WORDS		
0	70		
1	0		
2	0		
3	0		
BIT ERRORS			
BIT	ERRORS	PICKED-UP	DROPPED
0	0	0	0
1	2	1	1
2	0	0	0
⋮	⋮	⋮	⋮
22	0	0	0
23	0	0	0
<div>PREV</div> <div>NEXT</div> <div>CANCEL</div>			

This window is not active until modes are set in the POFA CONFIGURATION window. All fields are view-only.

#### How to Use the BIT DISPLAY Window:

1. Use PREV and NEXT to view the status of other reporting stations. These are inactive in single-station mode.
2. Click CANCEL to close the window.

#### BIT DISPLAY Window Fields:

##### **OWNSTATION**

Ownstation number.

##### **REPORTED STATION**

In single-station mode, this number is Ownstation number. In multi-station mode, the lowest numbered reporting station is displayed when the window opens.

**PARITY STATUS**

Number of test pattern words received with parity status 0, 1, 2, or 3.

**BIT ERRORS**

The BIT ERRORS box contains four columns:

BIT—lists 24 bits, 0-23.

ERRORS—sum of picked-up errors and dropped errors for each bit.

PICKED-UP—total picked-up errors for each bit.

DROPPED—total dropped errors for each bit.

## Interrupt Codes

Use this button to view interrupt codes and error counts. Wrong interrupt codes indicate either a malfunction in the system or an older model DTS. Although an older DTS will indicate errors in the WRONG INTERRUPT OCCURRENCES list, these codes are handled correctly by the system.

Click INTERRUPT CODES to open the POFA INTERRUPT CODES window.

POFA MULTI-STATION INTERRUPT CODES

OWN STATION NO 30

1) END RECV - NO PTR	0
2) END RECV - INCOMPLETE	0
3) PTT - NO END RECV	17
4) PTT - NO END RECV DATA	0
5) CONSECUTIVE PTTs	0
6) CONSECUTIVE PTRs	261
7) CONSECUTIVE PTR W/O DATA	171

EF HISTORY: 0 0 0 0 0 0

WRONG INTERRUPT OCCURRENCES

CODE	# ERRORS
0	0
1	0
4	0
7	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0

CANCEL

This window is not active until modes are set in the POFA CONFIGURATION window. All fields are view-only.

#### About the POFA INTERRUPT CODES Window:

The POFA INTERRUPT CODES window contains:

- A list of conditions (1-17) in which interrupt codes were received.
- Invalid interrupt codes (0,1,4,7 and 10-17) and the number of occurrences for each code.
- Last six External Functions (EF) received from DTS, such as PTTs and PTRs.

Click CANCEL to close the window.

## Multi-Station Matrix

If POFA is in single-station mode, the MULTI-MATRIX button will be inactive in the SINGLE-STATION SUMMARY window. All buttons will be active in the MULTI-STATION SUMMARY window.

Use this button to view error rates between reporting stations.

Click MULTI-STATION MATRIX from the POFA SUMMARY window to open the POFA MULTI-STATION MATRIX window.

OWN STATION NO: 30

REF PU	1	5	12	...
1	0	450/0	1200/0	...
5	450/6	0	673/0	...
12	1200/0	784/2	0	...
⋮	⋮	⋮	⋮	⋮
AIR TIME	00:00	00:00	00:00	...
WDS XMIT	2100	645	1352	...
WDS RECV	9660	574	957	...

CANCEL

This window is not active until modes are set in the POFA CONFIGURATION window. The fields are view-only. Click CANCEL to close window.

#### POFA MULTI-STATION MATRIX Window Fields:

##### **OWNSTATION**

Number of Ownstation.

##### **REF PU**

Reference number of each participating unit (PU).

- The PU numbers listed across the top of the box are the stations that report directly to Ownstation.
- The PU numbers listed in a column directly below "REF PU" are all reporting stations participating in the test. These stations report directly to Ownstation or to another station in the area which is reporting directly to Ownstation.
- The PU numbers are listed in numerically ascending order.
- For each PU combination, the matrix displays the ratio of total words

received to the number of errors.

**AIR TIME**

Total time the reporting station has been transmitting in a multi-station test.

**WRDS XMIT**

Total words transmitted by the station.

**WRDS RECV**

Total words received by the station.

## Notes



## ***Appendix A: TADIL-B***

---

When using the ATACC/TAOM implementation, some windows contain additional fields to configure and view the status of TADIL-B. These additional fields are described in this appendix.

## Link-11 Channel Edit Window

---

The TADIL-B CONFIG box is added to the EDIT LINK11 ACTIVE window to set the server, data rate, and clock source.

The screenshot shows a window titled "EDIT LINK11 ACTIVE". Inside, there are two main sections. The top section, labeled "CHANNEL", contains fields for "NAME" (set to "LINK11"), "INTERFACE" (set to "LINK11ACT"), "DEVICE" (set to "NTDS0" in a dropdown menu), and "MACHINE" (set to "MACH1" in a dropdown menu). The bottom section, labeled "TADIL B CONFIG", contains a "SERVER" dropdown menu set to "MACH 2", a "DATA RATE" section with three radio buttons (600, 1200, 2400) where 1200 is selected, and a "CLOCK SOURCE" section with two radio buttons (EXTERNAL, INTERNAL) where EXTERNAL is selected. At the bottom of the window are two buttons: "- OK -" and "CANCEL".

- > To configure TADIL-B server:
1. Click the SERVER select button and choose a machine to be the TADIL-B server.
  2. Select DATA RATE.
  3. Select CLOCK SOURCE.
  4. Click OK to accept the changes, or CANCEL to discard.

*TADIL-B CONFIG Box***SERVER**

Machine that controls TADIL-B communications.

**DATA RATE**


Baud rate of TADIL-B interface.

**CLOCK SOURCE**

Internal or external clock source for TADIL-B port.

## TADIL-B Supervisor

If the TADIL-B server connection is not established when the Link channel is started, the TADIL-B SUPERVISOR window opens.



- > To use the TADIL-B SUPERVISOR window::
- Establish a connection to the TADIL-B server and click TRY AGAIN.
  - Click TADIL A ONLY to use only TADIL A.
  - Click TERMINATE ALL TADIL to discard the process.

## Receive Quality

The TADIL-B PORTS box is added to the LINK MONITOR window to view the status of the TADIL-B ports. Status is set in the LINK CONFIGURATION window.

Link Monitor									
STATUS:RECEIVE.ONLY			STATUS		DELTA LAT: 0031S DELTA LNG: 00229E				
			#PTRs: 124 #PTTs: 54						
RECEPTION QUALITY							TADIL-B PORTS		
Source of RQ Report							PORT	RU	STATUS
Ref PU	10	21	30	40	50	76			
10	N/A	7		7	3	7	1	NIA	OFFLINE
21	7	N/A		7	3	7	2	NIA	OFFLINE
30	0	0	N/A	0	0	0	3	NIA	OFFLINE
40	7	7		N/A	3	7	4	141	OPERATIONAL
50	7	7		7	N/A	7	5	NIA	OFFLINE
76	4	4		4	2	N/A	6	101	ACTIVE
NCT	5	5	0	5	3	5	7	151	OPERATIONAL
CNTR-RCV/XMIT	134	133	0	133	134	134	8	NIA	READY
GMT	15:34:37	15:34:38	00:00:00	15:34:38	15:34:40	15:34:42			
Received Message Error Rate: 0%									
CLEAR			CANCEL			HELP			

### *TADIL-B PORTS Box*

#### **PORT**

Port physically connected to TADIL-B server.

#### **RU**

Address of the reporting unit connected on the port.

#### **STATUS**

Status of the port.

**OFFLINE**—port is deactivated.


**READY**—port is activated, but there is no unit at the other end of the circuit.

**ACTIVE**—port is activated and a unit is at the other end of the circuit, but the connection is not complete.

**OPERATIONAL**—port is activated and connection is complete. Track data and other information can be transferred only on an **OPERATIONAL** port. If no messages are received from the connected system for one minute, the status returns to **READY**.

## Link Status

The TADIL-B PORTS box is added to the LINK CONFIGURATION window to activate or deactivate ports and configure message forwarding.



> To use the TADIL-B PORTS Box:

1. Toggle checkboxes for ports ON or OFF.
  - Each checkbox represents a circuit attached to the physical connection on the TADIL-B server.
  - When a port is toggled ON, the port is activated and the status is set to READY.
2. Click FWD FILTER to configure message forwarding (described in *Forwarding Filter*).

### Forwarding Filter

Use the FORWARDING FILTER window to establish routes for forwarding messages. Each row represents a receiving port and each column represents a transmitting port.

**Tadil-B Forwarding Filter**

Filter Map

XMIT PORT

	A	1	2	3	4	5	6	7	8
A	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
1	<input checked="" type="checkbox"/>	-	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	<input type="checkbox"/>	<input type="checkbox"/>	-	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	-	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	-	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	-	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	-	<input type="checkbox"/>	<input type="checkbox"/>
7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	-	<input type="checkbox"/>
8	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	-

RCV PORT

RN#: NA 002 NA NA NA NA NA NA NA

SAVE EXIT

- > To establish forwarding routes:
1. Toggle ON checkboxes where receive port and transmitting port intersect.
    - In the figure above, messages received by TADIL A (A) are sent *only* to TADIL-B ports 1 and 2.
    - Messages received by TADIL-B port 1 are sent *only* to TADIL A (A) and TADIL-B port 2.
    - Messages received by other ports are not forwarded.
  2. Click SAVE to save the configuration.
  3. Click EXIT to close the window.

## GEO Filters

The TADIL-B PORTS box is added to the LINK-11 EDIT FILTER window to activate or deactivate ports for the filter.

LINK-11 EDIT FILTER

NAME:  
PRI:

CAT/THREAT  
STANDARD LINK-11/MISC

IGNORE  
BOX  
CIRCLE  
SECTOR  
ALLOW INSIDE  
ALLOW OUTSIDE

GEO LOCATION  
CENTER ON:  
FIXED POS  
OWNSHIP  
DLRP  
TN#

PORTS  
A  
1  
2  
3  
4  
5  
6  
7  
8

SAVE CANCEL

> To use the PORTS Box:

1. Toggle checkboxes for ports ON or OFF.
  - Each checkbox represents a circuit attached to the physical connection on the TADIL-B server.
  - When a port is toggled ON, tracks received or transmitted on this port are filtered according to the parameters set in the EDIT window.
2. Click SAVE when all parameters are set to save the filter.

## Notes



## Appendix B: MX512P Channel

Use the MX512P channel with a Data Terminal Set (DTS). To view and edit channel settings, highlight the MX512P channel in the COMMUNICATIONS window and click EDIT to open the EDIT MX512P CHANNEL window.

The screenshot shows the 'EDIT MX512P CHANNEL' window with the following settings:

- CHANNEL:**
  - NAME ..... MX512P
  - XREF ..... LPI
  - INTERFACE ..... MX512P
  - DEVICE ...
  - MACHINE ..
  - ☐ RECV      ☐ XON/XOFF
  - ☐ XMIT      ☐ RTS/CTS
  - ☒ AUTOSTART
- DATA TYPE:**
  - ☒ BAUDOT
  - ☐ ASCII
  - ☐ BINARY
- PARITY:**
  - ☒ NONE
  - ☐ EVEN
  - ☐ ODD
- STOP BITS:**
  - ☒ 1
  - ☐ 1.5
  - ☐ 2
- SOURCE:**
  - ☒ LINK A
  - ☐ LINK B
  - ☐ LINK C
  - ☐ LINK D
- DISPLAY HEAD:**
  - MACHINE ..
  - DISPLAY ..

Buttons at the bottom:

> How to use the COMMS EDIT window:

1. When the window first opens, data for the channel appears in the fields.
2. Modify the data.
  - Data fields (e.g., NAME): Cannot be edited.

- List fields (e.g., DEVICE): Click the right trackball button on the name of the device to show a list of available choices. Select a value from the list.
  - Checkboxes (e.g., AUTOSTART): Toggle ON or OFF.
  - Radio buttons (e.g., BAUDOT): Toggle ON one in each group.
3. Click OK to accept the changes. (Or click CANCEL to discard them.)
  4. If the channel is turned on while editing, clicking OK automatically stops the channel and restarts it with the new settings.

## COMMS EDIT Window Fields

### *CHANNEL Box*

#### **NAME**

Unique channel name. This field cannot be edited.

#### **XREF**

Unique three-character communications cross-reference code for the channel. This field cannot be edited.

#### **INTERFACE**

Communications interface for the channel. This field cannot be edited.

#### **DEVICE**

Device name (tty serial port) used for this channel.

#### **MACHINE**

Name of the machine used to transmit or receive messages on this channel.

### *DISPLAY HEAD Box*

Machine where the Data Terminal Set Control Head window is displayed.

**The following fields in the channel edit window are not yet implemented:**

#### **RECV**

Sets the channel to receive messages.

**XMIT**

Sets the channel to send messages.

**XON/XOFF**

XOFF (checkbox is empty)—system stops transmitting data.

XON (checkbox filled)—system resumes data transmission.

Note: If the BAUDOT radio button is selected in the DATA TYPE box, the XON/XOFF checkbox is “ghosted” and is unavailable.

**RTS/CTS**

A Request to Send (RTS) message is sent to wake up the receiving workstation before a real message is transmitted. The receiving workstation replies with a Clear to Send (CTS) message to indicate that it is prepared to receive data.

Use this checkbox when there are high baud rates to ensure against data loss.

**AUTOSTART**

Automatically turn on the channel at system startup.

*DATA TYPE Box*

Type of data to transmit or receive over the selected channel—BAUDOT, ASCII, or BINARY.

*PARITY Box*

Parity of the transmissions over the selected channel—NONE, EVEN, or ODD.

*STOP BITS Box*

Number of stop bits for transmission—1, 1.5, or 2.

*SOURCE Box*

Four radio buttons appear in this box: LINK A, LINK B, LINK C, and LINK D indicating the source of the channel.

## Data Terminal Set Control Head

When the MX512P channel is started a window similar to the one shown below opens to provide remote control of the DTS.

DTS CONTROL HEAD			
Multi-tone	Link-11	[ ] Page 1	[ ] START
[ ] Emcon:	TX ENABLED	[ ] Sta Mode:	NCS
[ ] Net Mode:	ROLL CALL	[ ] Recv Sb:	AUTO
[ ] Network Defaults		[ ] Test Mode:	OFF
[ ] Station Addr:	40	[ ] Addr List	
10	40		
STATUS		SIG QUALITY	
		USB	
		LSB	

This window is similar to the one on the front of some Data Terminal Sets and allows the user to configure and control the DTS. Refer to the DTS documentation for information about the fields and settings in this window.

---

## *Appendix C: Acronyms*

---

ADP	Automatic Data Processing
ALT	Altitude
AMP	Amplification
AMP CHAR	Amplifying Characteristics
AOP	Area of Probability
AOU	Area of Uncertainty
ACQSTN	Acquisition
ASW	Anti-Submarine Warfare
ATDL1	Army tactical data link 1
BBOX	Bearing Box
BRG	Bearing
CANTCO	Can't Comply
CANTPRO	Can't Process
CAT/THREAT	Category and Threat
CASS	Command Active Sonobuoy System
COMCNT	Commencement
COMMS	Communications
CONV	Conventional
CSE	Course
CTSX	Central Track Store Index
DI	Discrete Identifier
DICASS	Directional Command Active Sonobuoy System

DIFAR	Directional Finding and Ranging
DLRP	Data Link Reference Point
DR TYPE	Data Report Type
DTG	Date-time Group
DTS	Data Terminal Set
ECM	Electronic Control Message
EF	External Functions
EP	Estimated Position
ESM	Electronic Support Message
EST	Established
FTN	FOTC Track Number
GC	Great Circle
GEO	Geographic
GMT	Greenwich Mean Time
H-WIDTH	Half-width
ID	Identification
ID AMP	Identity Amplifier
IFF	Identification Friend or Foe
INV	Inventory
JRSL	Jammer received signal level
JTN	TADIL-J Track Number
LAT/LONG	Latitude and Longitude
LOFAR	Low-Frequency Acquisition and Ranging
LLTV	Low-Light-Level Television
MAD	Magnetic Anomaly Detection

---

NAV	Naval
NCT	Net Cycle Time
LTN	Local Track Number
NRT	Non-real Time
NTDS	Naval Tactical Data System; Naval Tactical Display System
NU-TRK	New Track
OBSRVTN	Observation
ORIG	Origin
PIF	Pseudo Identification Feature ; Personal Identification Feature
POFA	Programmed Operational Functional Appraisal
PRF	Pulse Repetition Frequency
PRI AMP	Primary Amplifier
PT AMPLIFY	Point Amplify
PT TYPE	Point Type
PTR	Prepare To Receive
PTT	Prepare To Transmit
PU	Participating Unit
PU/RU	Participating Unit or Reporting Unit
RECV	Receive
REF	Reference
RE-XMIT	Retransmit
RL	Rhumbline
RNG	Range
SMJR	Semi-major (axis)
SMNR	Semi-minor (axis)

SPCL	Special
SPD	Speed
SPI	Special Processing Indicator
SPP	Sound Propagation Path
SRC FREQ	Source Frequency
SSN	Nuclear Submarine
STN	System Track Number
TADIL	Tactical Data Link; Tactical Digital Information Link
TN	Track Number
TQ	Track Quality
TRK	Track
UB	Unified Build
UID	Unique Identifier
USMC	United States Marine Corps
WILCO	Will Comply
XMIT	Transmit
XREF	Cross-reference